

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPPLICATE *
(Other Instructions on
reverse side)

Budget Bureau No. 1004-0135
Expires August 31, 1985

CLSK

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT - " for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☐ P & A		5. LEASE DESIGNATION AND SERIAL NO. LC-029418-A	
2. NAME OF OPERATOR The Wiser Oil Company		6. IF INDIAN, ALLOTTEE OR TRIBE NAME Skelly Unit	
3. ADDRESS OF OPERATOR P.O. Box 2568 Hobbs, New Mexico 88241		7. AGREEMENT NAME WELL API NO. 30-015-05363	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 1980' FNL & 1980' FWL Sec. 23-T17S-R31E Unit F		9. WELL NO. 48	
10. FIELD AND POOL, OR WILDCAT Grayburg Jackson 7-Rivers		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 23-T17S-R31E	
14. PERMIT NO	15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3870' DF	12. COUNTY OR PARISH Eddy	13. STATE NM

16. Check Appropriate Box to indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT OFF ☐	PULL OR ALTER CASING ☐
FRACTURE TREAT ☐	MULTIPLE COMPLETE ☐
SHOOT OR ACIDIZE ☐	ABANDON* ☒
REPAIR WELL ☐	CHANGE PLANS ☐
(Other) ☐	

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐	REPAIRING WELL ☐
FRACTURE TREATMENT ☐	ALTERING CASING ☐
SHOOTING OR ACIDIZING ☐	ABANDONMENT* ☐
(Other) ☐	
(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)	

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS: (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

1. Set CIBP @ 3100'. Spot 35' cement on CIBP.
2. Circulate hole with mud.
3. Spot 50 sks. cement @ 2000'.
4. Perforate @ 750'.
5. Set cement retainer @ 700'. Pump 75 sks. cement.
6. Spot 20 sks. cement @ surface plug.
7. Install dry hole marker. Clean location.

SEE ATTACHED FOR
CONDITIONS OF APPROVAL

RECEIVED
1997 JUL 29 A 10:35
BUREAU OF LAND MGMT.
ROSWELL OFFICE

18. I hereby certify that the foregoing is true and correct.

SIGNED A. M. Jones TITLE Superintendent DATE July 22, 1997

(This space for Federal or State office use)

APPROVED BY (ORIG. SGD.) ALEXIS C. SWOBODA

TITLE PETROLEUM ENGINEER

DATE JUL 31 1997

CONDITIONS OF APPROVAL, IF ANY:

*See Instruction On Reverse Side