

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

Oil Cons.
N.M. DIV-Dist. 2
1301 W. Grand Avenue
Artesia, NM 88210
FORM APPROVED
Bureau of Land Management
E.O. 12812, March 31, 1993

C15F

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☐ Gas Well ☒ Other SWD Well

2. Name of Operator

PREMIER OIL & GAS, INC.

3. Address and Telephone No.

P.O. BOX 1246, Artesia, NM 88211-1246 505-748-2093

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

560 FSL 1690 FWL, Section 19 T-17S R-31E UNIT N

5. Lease Designation and Serial No.

LC-031844

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

FREN OIL CO

8. Well Name and No.

FREN OIL CO #21

9. API Well No.

30-015-10610

10. Field and Pool, or Exploratory Area

WOLF CAMP

11. County or Parish, State

EDDY, NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☒ Other Wolfcamp Completion
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

This well was temporarily abandoned in January, 2000, and approved by BLM in April, 2000.
A 7" CIBP was set at 11980'.

Premier Oil & Gas desires to attempt a Wolfcamp completion as follows:

- 1) Dig working pit.
- 2) Perforate Wolfcamp with 2 shots per ft. as follows: 8606-14', 8668-82', 8688-96', 8700-08', 8798-14', 8840-46', 8876-78', 8890-94', 8903-08', 8914-18', 8930-34'.
- 3) Trip in hole w/8550' 2-3/8" tubing w/packer; spot acid across perms. Acidize Wolfcamp w/4000 gals NEFE 15% acid.
- 4) Swab & test Wolfcamp.
- 5) Clean location & cover pit.

Please note that this completion will only be a 40-acre completion of Unit N so will no longer be a communitization.

14. I hereby certify that the foregoing is true and correct

Signed Rosalie Jones Title President

Date 02/12/02

(This space for Federal or State office use)

Approved by (ORIG. SGD.) ALEXIS C. SWOBODA

Title PETROLEUM ENGINEER

Conditions of approval, if any:

Date FEB 14 2002

RECEIVED

2002 FEB 13 AM 8:33

BUREAU OF LAND MGMT
ROSWELL OFFICE