

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs NM 88240

DISTRICT II
811 South First, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd, Aztec, NM 87410

OIL CONSERVATION DIVISION
2040 South Pacheco
Santa Fe, New Mexico 87505

WELL API NO.
30-015-20121

5. Indicate Type of Lease
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.
B-8095

7. Lease Name or Unit Agreement Name
Etz C State

8. Well No.
12

9. Pool name or Wildcat
Grayburg Jackson, 7RVS,QN,GB,SA

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
GR-3671

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS).

1. Type Of Well:
OIL WELL ☐ GAS WELL ☒ OTHER

2. Name of Operator
Mack Energy Corporation

3. Address of Operator
P.O. Box 960, Artesia, NM 88211-0960

4. Well Location
Unit Letter F : 1980 Feet From The North Line and 2310 Feet From The West Line
Section 16 Township 17S Range 30E NMPM Eddy County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
GR-3671

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Mack Energy Corporation proposes to plug and abandon as follows:

1. Run in hole w/tbg, tag CIBP @ 1905', spot cement plug from PBTD 1905' to 1805', Tag plug @ 1805'
2. Spot 100' plug 50' in and out 8 5/8" shoe @ 563', (610-510')
3. 10sx Surface plug.
4. Install Dry hole Marker and clean location



I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Crissa D. Carter TITLE Production Analyst DATE 3/30/2000

TYPE OR PRINT NAME Crissa D. Carter TELEPHONE NO. (505)748-1288

(This space for State Use)

APPROVED BY Signed by Tim TITLE _____ DATE 3-31-00

CONDITIONS OF APPROVAL, IF ANY:

AFTER

Surface plug 10sks

8 5/8" 24# @ 563' Cmt w/50sks.

Spot 100' plug 50' in and out 8 5/8" shoe @ 563', (610-510)

5 1/2" 14#&15.5# @ 2079' Cmt 100sks.

CIBP @ 1905'

**Set CIBP @ 1905', tag spot 100' cmt. plug from
PBTD at 1905' back to 1805'**

Open hole 2070-2100'

