

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Fina Oil & Chemical Company

3. ADDRESS OF OPERATOR

P.O. Box 2990, Midland, Texas 79702-2990

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

1650' FNL & 1650' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DP, RT, GR, etc.)

KB - 3543' (12.5' AGL)

5. LEASE DESIGNATION AND SERIAL NO.

NM 0107697

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

Jones Federal

8. FARM OR LEASE NAME

Jones Federal

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

Lusk Strawn

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 25, T19S, R31E

12. COUNTY OR PARISH

Eddy

13. STATE

NM

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT*

(Other)

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

- Set CIPB plus 10' cmt plug above fish @ 7070' to isolate Strawn perms @ 11,414-456'.
- Determine free point of 5-1/2" csg & pull as much pipe as possible.
- Set 100' cmt plug w/50' above & below top of 5-1/2" csg.
- Set 8-5/8" CIBP & 10' cmt. Plug above hole in csg @ 3752' to isolate bad section.
- Set 10' cmt plug @ surface.
- Cut csg off @ 3' below ground level & weld steel cap on 13-3/8" csg.
- Erect permanent steel marker.
- Restore location to natural state.

NOTE: Hole will be filled with 9.5" mud in all spaces not filled with cmt.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Petrotechnical Associate

DATE 1/8/91

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: