

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TRIPL. TE\*  
(Other instructions on re-  
verse side)Form approved.  
Budget Bureau No. 42-R1424.5. LEASE DESIGNATION AND SERIAL NO.  
SlupNM 13707 DIG NM 342

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

|                                                                                                                                                              |                                                                     |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------|
| 1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> Salt Water Disposal                         | 7. UNIT AGREEMENT NAME                                              |
| 2. NAME OF OPERATOR<br>ROGER C. HANKS                                                                                                                        | 8. FARM OR LEASE NAME<br>M. Foster                                  |
| 3. ADDRESS OF OPERATOR<br>P. O. Box 3148, Midland, Texas 79701                                                                                               | 9. WELL NO.<br>1                                                    |
| 4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)<br>At surface<br>660' FWL and 660' FNL | 10. FIELD AND POOL, OR WILDCAT<br>Undesignated                      |
| 14. PERMIT NO.<br>Case #5455, Order R-4158B                                                                                                                  | 11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA<br>5-20S-25E, NMPM |
| 15. ELEVATIONS (Show whether DF, RT, GR, etc.)<br>3531 GR                                                                                                    | 12. COUNTY OR PARISH<br>Eddy                                        |
|                                                                                                                                                              | 13. STATE<br>NM                                                     |

## 16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

5-3-75

Rig unit up.

Unseat Packer.

Pick up Halliburton RBP & RTTS. Run in hole, set RBP @ 6600'. Spt 3 sx on RBP. Pull 5 stands of tubing, set RTTS @ 6290'. Break down perfs. Pump 50 sx Class C. Cement. Displace cement past RTTS & 1000' in rest of cement. Shut well in with 750#.

5-4-75

Pres. test squeeze 1500# for 30 miha. No leaks. Pull out of hole. perf. squeeze holes at 6000'. Run RTTS to 5800' and set. Pump 30 BBLs water at 4 BPM at 1500#. Pump 500 sx Class C Cement with 5# salt/sk. Displace tubing with water, shut in with 750#. Wait 6 hrs. Run temp. survey (top of cement) 3500'.

5-5-75

Unseat RTTS & start out of hole. Shut down due to high wind.  
(over)

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Production Secretary

DATE 5/13/75

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

\*See Instructions on Reverse Side

APPROVED  
MAY 15 1975  
H. L. BEEKMAN  
ACTING DISTRICT ENGINEER

## Instructions

**General:** This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

**Item 4:** If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

**Item 17:** Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

(cont.)

G.P.O. : 1973- 780-622 /VIII- 148

5-6-75

Pull out of hole. Lay down RTTS. Pick up 4-3/4" bit and 2 drill collars. Run in hole, tag cement. Rig up reverse unit. Drill cement, 1st plug - 448' cement. 2nd plug - 420' cement. Circulate sand off of RBP. Tested squeeze to 1500# in 30 min. No leak.

5-7-75

Pull RBP. Lay down 2-7/8" tubing. Pump 500 gal. 15% acid. Overflush. Run Baker Model F.A. packer. Set on wire line at 4007'. Pick up 3-1/2" 10rd reg. tubing & pump 60 BBLs packer fluid. Corrosion inhibitor and oxygen scavenger. Space well out. Lay second suction to pump. Hook up and start.

bmc