

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

WT 851
SUBMIT IN TRI
(Other instructio.
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

New Mexico 04097

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Federal "Hx"

9. WELL NO.

1-20

10. FIELD AND POOL, OR WILDCAT

North Hackberry-Tates

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 20, T19N., R31E.

12. COUNTY OR PARISH 13. STATE

Eddy

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL ☐ GAS ☐
WELL WELL OTHER **DRY HOLE**

2. NAME OF OPERATOR

John M. Trigg

3. ADDRESS OF OPERATOR

P. O. Box 520, Roswell, New Mexico, 88201

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

2210' From North Line & 2310' From East Line

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3423.5 Gr.

3423.5 DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON* ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)*

**Per verbal instructions and approval received from U. S. G. S. on
May 7, 1964, we propose to plug this test at T.D. 2206' in dolomite
as follows:**

- 1. Attempt to salvage approximately 400 feet of the
8 5/8 inch casing.**
- 2. Set cement plugs as follows:
35 sack plug from 2000 - 2100 feet
35 sack plug from 550 - 650 feet
10 sack plug at the surface**
- 3. Set a regulation marker pipe.**
- 4. Leave all voids full of good mud.**
- 5. Level and clean up the location.**

RECEIVED

JUN 23 1964

O. C. C.
ARTEBIA, OFFICE

18. I hereby certify that the foregoing is true and correct

SIGNED ORIGINAL SIGNED BY

TITLE

Geologist

DATE **May 7, 1964**

(This space for record of State office use)

APPROVED BY
CONDITION OF APPROVAL, IF ANY

TITLE

DATE

JUN 22 1964
RONNIE E. SHOOK
ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.