

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPI
(Other instructions
reverse side)

TE
FC

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

NM-045275

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Vicki Federal

9. WELL NO.

10. FIELD AND/OR SURVEY

No. 1, Bore Spring
South of Draw Road
11. SEC. T., R., M., OR BLK. AND
SURVEY OR AREA

26-20S-24E

12. COUNTY OR PARISH

Eddy

13. STATE

NM

SUNDRY NOTICES AND REPORTS ON WELLS
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☒ OTHER ☐

2. NAME OF OPERATOR

Conoco Inc.

3. ADDRESS OF OPERATOR

P.O. Box 460 - Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1980' FNL & 1986' FFL - Unit Letter C AUG 09 '88

14. PERMIT NO.

30-015-20457

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3050 GR

C. D.
ARTESIA, OFFICE

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. MIRR. Tag cement retained.
 2. G/H to 3700' w/ 1/4" open-ended. Pump 27 sxs class H cement & spot just plug on top of retained at 3700'. Displace w/ 19 bbls mud. [TAG] SSS
 3. POOH to 3454'. Pump 80 bbls mud to circulate hole full.
 4. POOH to 1152'. Pump 25 sxs class H cement to isolate intermediate csg shoe. Displace w/ 5 bbls mud.
 5. POOH to 524' & pump 25 sxs class H cement. Displace w/ 1 bbl mud. POOH to 50' & circulate 10 sxs cement to surface.
 6. Install P&A marker.
- If you have any questions contact Clyde Finley at 397-5564.

18. I hereby certify that the foregoing is true and correct

SIGNED

Cecil O. Pugh

TITLE Administrative Supervisor

DATE

July 28, 1988

(This space for Federal or State office use)

APPROVED

TITLE

DATE

8-8-88

COMMENTS OF APPROVAL, IF ANY

*See instructions on Reverse Side