

Form 9-331
(May 1963)UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on reverse side)Form approved.
Budget Bureau No. 42-R1424

5. LEASE DESIGNATION AND SERIAL NO.

NM 936

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ Dry Hole2. NAME OF OPERATOR
Cities Service Oil Company3. ADDRESS OF OPERATOR
Box 63 - Hobbs, New Mexico 882404. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface 1000' FNL and 2000' FNL of loc.

30-T255-R24E, Eddy Co., New Mexico

14. PERMIT NO.

15. ELEVATIONS (Show whether DE, RT, GR, etc.)
4017 DE9. WELL NO.
1-Y10. FIELD AND POOL, OR WILDCAT
Wildcat11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec. 30-T255-R24E12. COUNTY OR PARISH
Eddy13. STATE
New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

T.D. 7530 Line. Pre . to plug and abandon in the following manner:

1. Displace 35 sack cement plug across PST #2 interval 6730-6830.
2. Displace 35 sack cement plug across top of Strawn 6530-6630.
3. Displace 35 sack cement plug across top of Wolfcamp 5940-6040.
4. Displace 35 sack cement plug across top of Dean 5630-5730.
5. Displace 35 sack cement plug ($\frac{1}{2}$ in and $\frac{1}{2}$ out of 1 5/8" set and cement & 3000' w/1000 sacks).
6. Set 10 sack cement surface. Plug 30' w/ 100 dry hole marker.
7. This plugging procedure was given direct approval by Mr. R. L. Beekman with your Artesia office.

RECEIVED
JUL 13 1970
U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICORECEIVED
JUL 14 1970

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Dist. Admin. Supervisor

DATE 1/1/73

(This space for Federal or State office use)

TITLE

DATE

APPROVED
ADDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

APPROVED

JUL 13 1970
R. L. BEEKMAN
ARTESIA, NEW MEXICO

Instructions

General: This form is designed for submitting proposals to perform certain well operations and reports on lands when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. (Consult local State or Federal office for specific instructions.)

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.