Form 3160-5 (March 2012)

## **UNITED STATES** DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

	0	0	20	145
DEC	3	U	21	)I)

Temporarily Abandon

Water Disposal

FORM APPROVED

OMB No	1004-0137
Expires: O	ctober 31, 20

Farmington F SUNDRY NOTICES AND REPORTS ON WELLS, Bureau of Lanc Do not use this form for proposals to drill or to re-enter an

5. Lease Serial No. NMSF 080107 6-If Indian, Allottee or Tribe Name

abandoned well.	Use Form 3160-3	(APD) for such proposa	ls.		
SUBMIT IN TRIPLICATE – Other instructions on page 2.				7. If Unit of CA/Agreement, Name and/or No.	
1. Type of Well			N/A		
✓ Oil Well Gas Well Other			8. Well Name and No. R R Zanotti # 001	8. Well Name and No. R R Zanotti # 001	
2. Name of Operator Encana Oil & Gas (USA) Inc.			9. API Well No. 30-039-05272		
3a. Address 370 17th Street, Suite 1700 Denver CO 80202		3b. Phone No. (include area code) 720-876-3448		10. Field and Pool or Exploratory Area Escrito Gallup Associated Pool	
4. Location of Well (Footage, Sec., 7 SHL: 560 FNL, 1980 FWL Section 34, T24N F BHL: 560 FNL, 1980 FWL Section 34, T24N F		ion)	11. County or Parish, Rio Arriba, New Me		
12. CHE	CK THE APPROPRIATE	BOX(ES) TO INDICATE NATUR	E OF NOTICE, REPORT OR OTH	ER DATA	
TYPE OF SUBMISSION		TY	YPE OF ACTION		
✓ Notice of Intent	Acidize Alter Casing	Deepen Fracture Treat	Production (Start/Resume) Reclamation	Water Shut-Off  Well Integrity	
Subsequent Report	Casing Repair	New Construction	Recomplete	Other Cement Squeeze	

13. Describe Proposed or Completed Operation: Clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports must be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 must be filed once testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has determined that the site is ready for final inspection.)

Plug and Abandon

Plug Back

Encana Oil & Gas (USA) Inc. proposes to perform two (2) cement squeezes on the RR Zanotti # 1 well as follows:

Change Plans

Convert to Injection

- Run in hole and set packer at 1790'.
- Mix up 130 sxs cement and squeeze below packer. 2.
- 3. PUH to 1500'

Final Abandonment Notice

- Mix up 70 sxs cement and squeeze below packer. 4.
- Drill out.
- Provide 24 hour notice to BLM and OCD prior to performing the MIT.

OIL CONS. DIV DIST. 3

JAN 07 2016

For any technical questions please contact Scott Reed, Production Engineer at 720-876-3238 or at 720-261-2295.

BLM'S APPROVAL OR ACCEPTANCE OF THIS ACTION DOES NOT RELIEVE THE LESSEE AND OPERATOR FROM OBTAINING ANY OTHER AUTHORIZATION REQUIRED FOR OPERATIONS ON FEDERAL AND INDIAN LANDS

SEE ATTACHED FOR CONDITIONS OF APPROVAL

14. I hereby certify that the foregoing is true and correct. Name (Printed Typed) Christopher G. Simmons	Title Regulatory Analyst	
Signature July Willy Williams	Date 12/28/2015	
THIS SPACE FOR FED	DERAL OR STATE OFFICE U	USE
Approved by  Abdels adir Simadan;  Conditions of approval, if any are attached. Approval of this notice does not warrant of that the applicant holds legal or equitable title to those rights in the subject lease which	Title PE	Date 1-4-16
entitle the applicant to conduct operations thereon.  Title 1811 S.C. Section 1001 and Title 1211 S.C. Section 1212 make it a crime for any	FFO	

fictitious or fraudulent statements or representations as to any matter within its jurisdiction

## **BLM CONDITION OF APPROVAL**

## CASING REPAIR, WORKOVER AND RECOMPLETION OPERATIONS:

- 1. If casing repair operations are needed, obtain prior approval from this office before commencing repairs. If a CBL or other logs are run, provide this office with a copy.
- 2. After any casing repair operations, test cement squeeze to a minimum of 500# for 30 minutes with no more than 10 % pressure fall off in the 30 minute test period. Provide test chart with your subsequent report of operations
- 3. A properly functioning BOP and related equipment must be installed prior to commencing workover, casing repair, and/or recompletion operations.
- 4. Contact this office at (505) 564-7750 prior to conducting any cementing operations

## SPECIAL STIPULATIONS:

- 1. Pits will be fenced during work-over operation.
- 2. All disturbance will be kept on existing pad.
- 3. All pits will be pulled and closed immediately upon completion of the recompletion and work-over activities.
- 4. Pits will be lined with an impervious material at least 12 mils thick.