Form 3160-5 (June 2015)

## **UNITED STATES** DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED OMB NO. 1004-0137 Expires: January 31, 2018

SUNDRY NOTICES AND REPORTS ON WELLS

NMNM99003

Lease Serial No.

Do not use this form for proposals to abandoned well. Use form 3160-3 (AP	6. If Indian, Allottee or Tribe Name		
SUBMIT IN TRIPLICATE - Other instructions on page 2		7. If Unit or CA/Agreement, Name and/or No.	
Type of Well     ☐ Oil Well    ☐ Gas Well    ☐ Other:		8. Well Name and No. WF FEDERAL 30 2	
2. Name of Operator Contact: PRISCILLA SHORTY HILCORP ENERGY COMPANY E-Mail: pshorty@hilcorp.com		9. API Well No. 30-045-31307-00-S1	
3a. Address 1111 TRAVIS STREET HOUSTON, TX 77002	3b. Phone No. (include area code) Ph: 505-324-5188	10. Field and Pool or Exploratory Area BASIN FRUITLAND COAL TWIN MOUNDS	
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)		11. County or Parish, State	
Sec 30 T30N R14W SESE 830FSL 1130FEL 36.780263 N Lat, 108.345468 W Lon		SAN JUAN COUNTY, NM	
12. CHECK THE APPROPRIATE BOX(ES)	TO INDICATE NATURE OF NOTICE,	REPORT, OR OTHER DATA	

TYPE OF SUBMISSION	TYPE OF ACTION				
■ Notice of Intent     □ Subsequent Report     □ Final Abandonment Notice	☐ Acidize ☐ Alter Casing ☐ Casing Repair ☐ Change Plans ☐ Convert to Injection	☐ Deepen ☐ Hydraulic Fracturing ☐ New Construction ☐ Plug and Abandon ☐ Plug Back	☐ Production (Start/Resume) ☐ Reclamation ☐ Recomplete ☑ Temporarily Abandon ☐ Water Disposal	☐ Water Shut-Off ☐ Well Integrity ☐ Other	

13. Describe Proposed or Completed Operation: Clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports must be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 must be filed once testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has determined that the site is ready for final inspection.

Hilcorp Energy Company requests permission to temporarily abandon the subject well with the intent to return the well to production once gas prices rise. Please see the attached procedure and wellbore schematic.

> Notify NMOCD 24 hrs prior to beginning operations

NMOCD

SEP 11 5 2019

DISTRICT III

14. I hereby certify that the foregoing is true and correct.  Electronic Submission #480046 verified by the BLM Well Information System  For HILCORP ENERGY COMPANY, sent to the Farmington  Committed to AFMSS for processing by JCHN HOFFMAN on 09/04/2019 (19JH0159SE)							
Name (Printed/Typed)	PRISCILLA SHORTY	Title	OPERATIONS REGULATORY TECH				
Signature	(Electronic Submission)	Date	08/22/2019				
THIS SPACE FOR FEDERAL OR STATE OFFICE USE							
Approved_ByJOHN_HOFFMAN			ETROLEUM ENGINEER  Farmington	Date 09/04/2019			

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on page 2) \*\* BLM REVISED \*\* BLM REVISED \*\* BLM REVISED \*\* BLM REVISED \*\*





## Hilcorp Energy Company WF FEDERAL 30-2

Temporarily Abandon API #: 3004531307

## PROCEDURE

- 1. Hold a pre-job safety meeting prior to beginning all operations or during a change in operational scope or initiation of SIMOPs. Properly document all operations via the JSA process. Insure that all personnel onsight abide by HEC safety protocol, including PPE, housekeeping, and procedures. Verify cathodic protection is off and wellhead instrumentation is properly disconnected from wellhead. Comply with all NMOCD, BLM, and HEC safety and environmental regulations. Verify there is no H2S present prior to beginning operations. If H2S is present, take the necessary actions to insure that the operation is safe prior to beginning operations. Observe and record pressures across all strings daily, prior to beginning operations. Notify NMOCD and BLM 24 hours in advance of beginning operations
- 2. MIRU service rig and associated equipment, ND casing risers
- 3. LOTO pumping unit, remove HH and bridle, PU on PR and unseat pump. POOH LD rods and pump.
- 4. ND tree and NU BOPs. Pressure and function test BOPs to 150/1500 psi.
- 5. PU on tbg, release hanger, scan and visually inspect tbg and POOH
- 6. PU junk mill and RIH to 900', POOH LD junk mill
- 7. RIH w/ CBIP on tbg and set at 850', PT CIBP and casing to 600 psi, POOH w/ setting tool.
- 8. RBIH w/ 250' of tbg to use as a kill string. NDNU tree verify tree and wellhead are equipped with functional pressure gauges. RDMO
- 9. Contact BLM and NMOCD to schedule witnessed MIT. PT csg to 600 psi.

