Form 3160-5 (June 2015)

■ Subsequent Report

☐ Final Abandonment Notice

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED OMB NO. 1004-0137 Expires: January 31, 2018

SUNDRY NOTICES AND REPORTS ON WELLS

5. Lease Serial No. NMNM25446

abandoned wel		6. If Indian, Allottee of	or Tribe Name			
SUBMIT IN 1		7. If Unit or CA/Agreement, Name and/or No.				
Type of Well Oil Well		8. Well Name and No. BISTI COAL 18 1				
2. Name of Operator Contact: ALICE MASCARENAS DJR OPERATING LLC E-Mail: amascarenas@djrllc.com				9. API Well No. 30-045-28140-00-S1		
3a. Address 1600 BROADWAY SUITE 196 DENVER, CO 80202	60	3b. Phone No. (include area code) Ph: 505-632-3476		10. Field and Pool or I BASIN FRUITLA		
4. Location of Well (Footage, Sec., T		11. County or Parish, State				
Sec 18 T25N R12W SWNE 25 36.401490 N Lat, 108.149250		SAN JUAN COUNTY, NM				
12. CHECK THE AF	PPROPRIATE BOX(ES)	TO INDICATE NATURE OF	F NOTICE, F	REPORT, OR OTH	HER DATA	
TYPE OF SUBMISSION	TYPE OF ACTION					
■ Notice of Intent	☐ Acidize	☐ Deepen	☐ Production	on (Start/Resume)	☐ Water Shut-Off	

☐ Hydraulic Fracturing

■ New Construction

☑ Plug and Abandon

■ Reclamation

□ Recomplete

■ Water Disposal

☐ Temporarily Abandon

13. Describe Proposed or Completed Operation: Clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports must be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 must be filed once testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has determined that the site is ready for final inspection.

□ Plug Back

DJR Operating, LLC request permission to Plug & Abandon the subject well per the attached procedure, wellbore diagram, and reclamation plan.

□ Alter Casing

□ Casing Repair

☐ Change Plans

☐ Convert to Injection

Notify NMOCD 24 hrs prior to beginning operations



■ Well Integrity

☐ Other

14. I hereby certify that the foregoing is true and correct. Electronic Submission #499283 verified by the BLM Well Information System For DJR OPERATING LLC, sent to the Farmington Committed to AFMSS for processing by JOE KILLINS on 01/15/2020 (20JK0084SE)						
Name (Printed/Typed)	ALICE MASCARENAS	Title	REGULATORY TECHNICIAN			
Signature	(Electronic Submission) THIS SPACE FOR FEDERA	Date	01/15/2020 STATE OFFICE USE			
Approved By JOE KILLINS			NGINEER	Date 01/16/2020		
Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.		Office	Farmington			
Title 18 U.S.C. Section 100	1 and Title 43 U.S.C. Section 1212, make it a crime for any po	rson kno	owingly and willfully to make to any department or a	gency of the United		

States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.



UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT FARMINGTON DISTRICT OFFICE

6251 COLLEGE BLVD. FARMINGTON, NEW MEXICO 87402

Attachment to notice of Intention to Abandon:

Re: Permanent Abandonment

Well: Bisti Coal 18-1

CONDITIONS OF APPROVAL

- 1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal and Indian Lease."
- 2. Farmington Office is to be notified at least 24 hours before the plugging operations commence (505) 564-7750.

GENERAL REQUIREMENTS FOR PERMANENT ABANDONMENT OF WELLS ON FEDERAL AND INDIAN LEASES FARMINGTON FIELD OFFICE

- 1.0 The approved plugging plans may contain variances from the following minimum general requirements.
 - 1.1 Modification of the approved plugging procedure is allowed only with the prior approval of the Authorized Officer, Farmington Field Office.
 - 1.2 Requirements may be added to address specific well conditions.
- 2.0 Materials used must be accurately measured. (densometer/scales)
- 3.0 A tank or lined pit must be used for containment of any fluids from the wellbore during plugging operations and all pits are to be fenced with woven wire. These pits will be fenced on three sides and once the rig leaves location, the fourth side will be fenced.
 - 3.1 Pits are not to be used for disposal of any hydrocarbons. If hydrocarbons are present in the pit, the fluids must be removed prior to filling in.
- 4.0 All cement plugs are to be placed through a work string. Cement may be bull-headed down the casing with prior approval. Cement caps on top of bridge plugs or cement retainers may be placed by dump bailer.
 - 4.1 The cement shall be as specified in the approved plugging plan.
 - 4.2 All cement plugs placed inside casing shall have sufficient volume to fill a minimum of 100' of the casing, or annular void(s) between casings, plus an excess volume sufficient to provide for 50 linear feet of fill above the plug.
 - 4.3 Surface plugs may be no less than 50' in length.
 - 4.4 All cement plugs placed to fill annular void(s) between casing and the formation shall be of sufficient volume to fill a minimum of 100' of the annular space plus 100% excess, calculated using the bit size, or 100' of annular capacity, determined from a caliper log, plus an excess volume sufficient to provide for 50 linear feet of fill above the plug.
 - 4.5 All cement plugs placed to fill an open hole shall be of sufficient volume to fill a minimum of 100' of hole, as calculated from a caliper log, plus an excess volume sufficient to provide for 50 linear feet of fill above the plug. In the absence of a caliper log, an excess of 100% shall be required.
 - 4.6 A cement bond log or other accepted cement evaluation tool is required to be run if one had not been previously ran or cement did not circulate to surface during the original casing cementing job or subsequent cementing jobs.

- 5.0 All cement plugs spotted across, or above, any exposed zone(s), when; the wellbore is not full of fluid or the fluid level will not remain static, and in the case of lost circulation or partial returns during cement placement, shall be tested by tagging with the work string.
 - 5.1 The top of any cement plug verified by tagging must be at or above the depth specified in the approved plan, without regard to any excess.
 - 5.2 Testing will not be required for any cement plug that is mechanically contained by use of a bridge plug and/or cement retainer, if casing integrity has been established.
 - 5.3 Any cement plug which is the only isolating medium, for a fresh water interval or a zone containing a prospectively valuable deposit of minerals, shall be tested by tagging.
 - 5.4 If perforations are required below the surface casing shoe, a 30 minute minimum wait time will be required to determine if gas and/or water flows are present. If flow is present, the well will be shut-in for a minimum of one hour and the pressure recorded. Short or long term venting may be necessary to evacuate trapped gas. If only a water flow occurs with no associated gas, shut well in and record the pressures. Contact the Engineer as it may be necessary to change the cement weight and additives.
- 6.0 Before setting any cement plugs the hole needs to be rolled. All wells are to be controlled by means of a fluid that is to be of a weight and consistency necessary to stabilize the wellbore. This fluid shall be left in place as filler between all plugs.
 - 6.1 Drilling mud may be used as the wellbore fluid in open hole plugging operations.
 - 6.2 The wellbore fluid used in cased holes shall be of sufficient weight to balance known pore pressures in all exposed formations.
- 7.0 A blowout preventer and related equipment (BOPE) shall be installed and tested prior to working in a wellbore with any exposed zone(s); (1) that are over pressured, (2) where the pressures are unknown, or (3) known to contain H_2S .
- 8.0 Within 30 days after plugging work is completed, file a Sundry Notice, Subsequent Report of Abandonment (Form 3160-5), five copies, with the Field Manager, Bureau of Land Management, 6251 College Blvd., Suite A, Farmington, NM 87402. The report should show the manner in which the plugging work was carried out, the extent, by depth(s), of cement plugs placed, and the size and location, by depth(s), of casing left in the well. Show date well was plugged.
- 9.0 All permanently abandoned wells are to be marked with a permanent monument as specified in 43 CFR 3162.6(d). Unless otherwise approved.
- 10.0 If this well is located in a Specially Designated Area (SDA), compliance with the appropriate seasonal closure requirements will be necessary.

All of the above are minimum requirements. Failure to comply with the above conditions of approval may result in an assessment for noncompliance and/or a Shut-in Order being issued pursuant to 43 CFR 3163.1. You are further advised that any instructions, orders or decisions issued by the Bureau of Land Management are subject to administrative review pursuant to 43 CFR 3165.3 and appeal pursuant to 43 CFR 3165.4 and 43 CFR 4.700.

Plug and Abandonment Procedure

for

DJR Operating, LLC

Bisti Coal 18-1

API # 30-045-28140

SW/NE, Unit G, Sec. 18, T25N, R12W

San Juan County, NM

I.

- 1. Hold Pre job meeting, comply with all NMOCD, BLM and environmental regulations.
- 2. Check and record tubing, casing and bradenhead pressures.
- 3. Remove existing piping from casing valve, RU blow lines from casing valves and blow down casing pressure. Kill well as necessary. Ensure that well is dead or on a vacuum.
- 4. Trip out of hole with rods and pump. Lay down to be sent in for storage/salvage.
- 5. ND-WH, NU-BOP, function test-BOP.
- 6. Trip out of hole with 2 3/8" tubing. LD tubing to be sent in for storage/salvage.

H.

- 7. PU workstring, TIH with bit and scraper, make sure that the bit and scraper will go below 1330'. TOOH.
- 8. PU and RIH with a 4 ½" cement retainer. Set the CR at +/- 1330'. Pressure test tubing to 1000 psi, sting out of CR, test casing to 800 psi. If casing does not test, contact engineering.

Provided that casing test was good, proceed to step 9.

- 9. RU up cement equipment. Pump water to assure that tubing is clear.
- 10. Plug 1. Fruitland Coal, Kirtland, Ojo Alamo and surface casing shoe. From 1330 to surface, 121.3 cu ft, 105.5 sx Class G at 1.15 yield. With 50% excess = 158.2 sx. (or pump cement until circulation is achieved at surface.)

- 11. RD cementing equipment. Cut off wellhead, fill annuli with cement as necessary. Install P&A marker as per regulatory requirements. Record GPS coordinates for P&A marker and the Final P&A Report. Photograph the P&A marker and attach to the report.
- 12. RD and MO all rig and cement equipment. Assure that location is free of trash and contamination before moving off.
- 13. Send all reports and attachments to DJR Aztec office for regulatory filings.


Current Wellbore Diagram

DJR Operating, LLC

Bisti Coal 18-1

API # 30-045-28140 SW/NE, Unit G, Sec 18, T25N, R12W San Juan County, NM

GL 6505 KB N/A Spud Date 8/26/1990



Proposed Wellbore P&A Diagram DJR Operating, LLC

Bisti Coal 18-1 API # 30-045-28140 SW/NE, Unit G, Sec 18, T25N, R12W San Juan County, NM

> GL 6505 KB N/A Spud Date 8/26/1990

