

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO.

5. Indicate Type of Lease
STATE ☐ FEE ☒

6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☐ GAS WELL ☐ OTHER Injection

2. Name of Operator
American Exploration Company

3. Address of Operator
P.O. Box 10509, Midland TX 79702

4. Well Location
Unit Letter C : 1220 Feet From The North Line and 2600 Feet From The West Line

Section 7 Township 17N Range 8W NMPM McKinley County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

P&A.

1. MIRU WOR.
2. Circ hole w/ 9.0 ppg mud. OMIT
3. Spot cmt plug 1612' - 1412' (perfs 1585' - 1612').
4. Spot cmt plug 200' - surface. AMEND
5. Install P&A marker.

RECEIVED

JUN - 1/1992

OIL CON. DIV.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE David Dennard TITLE Engineer

TYPE OR PRINT NAME David Dennard

DIST. 3

DATE 5/27/92

TELEPHONE NO. (915) 687-0587

(This space for State Use)

APPROVED BY Suzanna J. Juchurst DEPUTY OIL & GAS INSPECTOR, DIST. #3 DATE 6/1/92

CONDITIONS OF APPROVAL, IF ANY: OMIT STEP 2. AMEND STEP 4 - PERFORATE 4 1/2" CGG AT 200' AND CIRC. CMT TO SURF LIP BRADENHEAD. LEAVE 4 1/2" CGG FULL OF CMT TO SURF. AFTER STEP 3 - WCC MIN. 3 HRS. TAG PLUG. IF PLUG IN PLACE - GO TO STEP 4. IF PLUG NOT IN PLACE. FILL TO 1412'