

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

SF 081325

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Federal <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator El Paso Natural Gas Company	8. Farm or Lease Name Bolack E
3. Address of Operator Box 990, Farmington, New Mexico	9. Well No. 4
4. Location of Well UNIT LETTER I , 1600 FEET FROM THE South LINE AND 1090 FEET FROM THE East LINE, SECTION 1 TOWNSHIP 23-N RANGE 6-W NMPM.	10. Field and Pool, or Wildcat Ballard Pictured Cliffs
15. Elevation (Show whether DF, RT, GR, etc.) 6769' DF	12. County Rio Arriba

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Due to non-commercial production, it is intended to plug and abandon this well in the following manner:

1. Spot 30 sack cement plug down tubing to cover 1960-2184'. Pull tubing.
2. Determine free point of the 5 1/2" casing. Shoot off casing at the free point. Spot 30 sack cement plug on 5 1/2" casing stub. Pull casing.
3. Install a 4" x 4' plug and abandonment marker and 5 sack cement plug in the top of the surface casing.

Note: If there is insufficient casing free to be economically recovered, operation number 2 will be omitted.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Original signature of Carl E. Matthews

TITLE Petroleum Engineer

DATE 10-4-66

APPROVED BY Emery C. Ames

TITLE Sup. Dist. III

DATE 10-5-66

CONDITIONS OF APPROVAL, IF ANY:

