

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on reverse side)Form approved.
Budget Bureau No. 42-R1424.
5. LEASE DESIGNATION AND SERIAL NO.NM 021478 (term.)
6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. UNIT AGREEMENT NAME	
2. NAME OF OPERATOR TEXACO, Inc.		8. FARM OR LEASE NAME Moore	
3. ADDRESS OF OPERATOR P. O. Box EE, Cortez, Colo. 81321		9. WELL NO. 1	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 330/S, 2310/EW		10. FIELD AND POOL, OR WILDCAT	
11. PERMIT NO.		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA 0-22-19N-3W	
15. ELEVATIONS (Show whether DF, RT, GR, etc.)		12. COUNTY OR PARISH Sandoval	
		13. STATE N. Mex.	

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Texaco, Inc. proposes to abandon the well as follows:

1. MIRUSU and run tubing.
2. Tag bottom. Spot 15 sx class B neat cement up to 1500' to cover liner top and pay zone.
3. WOC. Tag cement top; if below 1500', recement.
4. Fill hole with water.
5. Set cement plug from 500' to 350' (18 sx cement).
6. Set 30' surface plug in 5½" and 12" csg. (18 sx cement).
7. Erect marker and clean location.



18. I hereby certify that the foregoing is true and correct

SIGNED

Alvin R. Mance

TITLE

Field Foreman

DATE

7-25-77

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

USGS(4) NMOCC(3) GLE-ARM -JHP