

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. I-6952
7. Unit Agreement Name ---
8. Farm or Lease Name Armijo Reservoir
9. Well No. 1
10. Field and Pool, or Wildcat Wildcat <i>NY</i>
12. County Sandoval

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- 2. Name of Operator Wexpro Company 3. Address of Operator P. O. Box 458, Rock Springs, WY 82902 4. Location of Well UNIT LETTER <i>K</i> , 1980 FEET FROM THE South LINE AND 1980 FEET FROM THE West LINE, SECTION 16 TOWNSHIP 21 N RANGE 4 W NMPM.
15. Elevation (Show whether DF, RT, CR, etc.)

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TD 4350', PBD 1900', Perforations 1744'-1762'

As the present completion will not produce gas or oil in commercial quantities and no other zones appear to be capable of commercial production, we would like to plug and abandon the subject well by setting the following plugs:

Plug No. 1: 1812' to 1694' with 15 sacks

Plug No. 2: Perforate four holes at 450' and assuming that the hole will circulate, set cement retainer at 280', sting into retainer and squeeze 180 sacks of cement.

Plug No. 3: Set 10 sacks cement in top of 5-1/2-inch casing.

The casing flange will be removed and a regulation abandonment marker will be installed and the disturbed area will be rehabilitated.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Thomas P. Wadsworth TITLE Director, Petroleum Eng. DATE September 15, 1983

OIL CON. DIV.
DIST. 3

JAN 16 1984

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

DATE _____