(May 1963)	DEPARTMENT OF THE	HE INTERIOR	(Other instructions or verse side)	5. LEASE DESIGNATION	au No./42-R1424.	
GEOLOGICAL SURVEY  SUNDRY NOTICES AND REPORTS ON WELLS  (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  Use "APPLICATION FOR PERMIT—" for such proposals.)				NM-0176243  6. IF INDIAN, ALLOTTE	E OR TRIBE NAME	
OIL GAS WELL ATTER to abandon				7. UNIT AGREEMENT NA	ME	
2. NAME OF OPERATOR DAVIS OIL COMPANY				/	8. FARM OR LEAST NAME Schram-Hanson Federa	
3. Address of Operator 1230 Denve	er Club Bldg., - Denv	er, Colorado	80202	9. WELL NO. #1	son redera	
<ol> <li>LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.)</li> <li>At surface</li> </ol>				10. FIELD AND POOL, OF Snake Eyes	I	
660 FSL 1	980 FEL Sec. 17-T21	N-R8W		11. SEC., T., E., M., OR B SURVEY OR AREA		
14. PERMIT NO.	15. ELEVATIONS (3	Show whether DF, RT,	GR, etc.)	Sec. 17-21 12. COUNTY OR PARISH San Juan		
13.	Check Appropriate Box T	o Indicate Natu	e of Notice, Report,	or Other Data		
N	NOTICE OF INTENTION TO:		SUE	BSEQUENT REPORT OF:		
TEST WATER SHUT-OF FRACTURE TREAT	PULL OR ALTER CASI MULTIPLE COMPLETE		WATER SHUT-OFF	REPAIRING W		
SHOOT OR ACIDIZE	ABANDON*	<u>x</u>	FRACTURE TREATMENT SHOOTING OR ACIDIZING	ALTERING CA	·	
REPAIR WELL	CHANGE PLANS		(Other)			
17. DESCRIBE PROPOSED OR proposed work. If nent to this work.) *	COMPLETED OPERATIONS (Clearly st well is directionally drilled, give	ate all pertinent det subsurface locations	Completion or Rec	sults of multiple completion of completion Report and Log formates, including estimated date ertical depths for all markers	m.)	
	to abandon the Schra					
The pluggi	ng procedure would be	e as follows	:			
1. Spot 5 and su	O sx cement plug acro rface squeeze leaving	oss Dakota p g at least 5	erfs (4639-45), O' of cement abo	pull tubing above ove top perforation	e cement on.	
2. Pull f	ree casing, place 50 stub.	sx plug lea	ving 50' in stul	b and at least 50	cement	
3. Place	95 sx plug from 333'	(base of Pi	cture Cliffs 283	3') to at least 18	33'.	
4. Set dr	4. Set dry hole marker in top surface pipe with 5 sx.					
5. Clean a	5. Clean and level location.					
(It is	anticipated that Lar	ry Bedford,	Inc. will do the	ne work.)		
				OIL	2 8 1974 ON. COM. /	
18. I hereby certify that t	he foregoing is true and correct				31, 3	
signed	ne foregoing is true and correct	TITLE Product	ion Engineer	DATE		
(This space for Federa	il or State office use)					
APPROVED BYCONDITIONS OF APP	PROVAL, IF ANY:	TITLE		DATE		