

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPPLICATE\*  
(Other instructions on reverse side)

Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

**SF-078584**

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

**Miller "B"**

9. WELL NO.

**2**

10. FIELD AND POOL, OR WILDCAT

**Devils Fork Gallup**

11. SEC. T., R., M., OR BLK. AND SURVEY OR AREA

**Sec. 12-T24N-R7W**

12. COUNTY OR PARISH

**Rio Arriba**

13. STATE

**N. M.**

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

**Paul F. Rutledge**

3. ADDRESS OF OPERATOR

**P. O. Box 2303, Santa Fe, New Mexico 87501**

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\* See also space 17 below.)  
At surface

**1650' N. of S. line, 990' E. of W. line**

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

**6914 KB**

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON\* ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT\* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

**It is intended to plug and abandon this well in the following manner:**

1. Set 100' cement plug 5850 to C.O.T.D., across perforations.
2. Set 100' cement plug, inside casing, 3900'-4000' across top of Mesa Verde.
3. Perforate at 2500'.
4. Set 150' cement plug, inside and outside casing, 2350'-2500', across Pictured Cliffs.
5. Perforate at 1950'.
6. Set 200' cement plug, inside and outside casing, 1750'-1950', across Ojo Alamo.
7. Put 5 sack cement in annulus and 10 sacks in top of cut off 4 1/2" casing and install dry hole marker.

RECEIVED

DEC 24 1970

U. S. GEOLOGICAL SURVEY  
DURANGO, COLO.

18. I hereby certify that the foregoing is true and correct

SIGNED

**P. F.**

TITLE

**President, Walsh Engineering & Production Corp.**

DATE

**12-28-70**

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

Distribution:

**5 copies, USGS, Durango,**

**1 copy, Paul F. Rutledge**

**Colorado**

See instructions on Reverse Side

## Instructions

**General:** This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

**Item 4:** If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

**Item 17:** Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

U.S. GOVERNMENT PRINTING OFFICE: 1963-O-685229

