1 - File

Form Approved.

Form 9-331 Dec. 1973

Budget Bureau No. 42-R1424 UNITED STATES DEPARTMENT OF THE INTERIOR 6. IF INDIAN, ALLOTTEE OR TRIBE NAME **GEOLOGICAL SURVEY**

7. UNIT AGREEMENT NAME 8. FARM OR LEASE NAME
D4 U44
Big Hit 9. WELL NO.
#12
10. FIELD OR WILDCAT NAME
Gavilan Pictured Cliff / (UCA)
11. SEC., T., R., M., OR BLK. AND SURVEY OR
AREA
Sec 12 T24N R2W
12. COUNTY OR PARISH 13. STATE
Rio Arriba NM
14. API NO.
15. ELEVATIONS (SHOW DF, KDB, AND WD)
7368' G.L.
EIVED
(NOTE: Report results of multiple completion or zone
1 Conange on Form 9–330.)
AND MAGRICULANT Emportació a rga
and the second of the second o

DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Plan to plug and abandon well as follows:

1. Squeeze 5 sx cement plug into perfs 2390-2402'.

2. Spot 10 sx cement plug 2390 to 2258'.

3. Spot 10 sx cement plug 132' to surface.

4. Install dry hole marker.

- Install dry hole marker.
- Restore surface.

Do not plan to pull $4\frac{1}{2}$ " casing - casing cemented to surface.

1			
Subsurface Safety Valve: Manu. and Type	·		- Separoveder.
18. I hereby certify that the foregoing is true	e and correct		AS AMENDED
SIGNED / I I Isaal	TITLEGeologist	DATE	9-12-84 SED 17 1984 A Hener
Jim I. Jacol	This space for Federal or State office use)		SEP 17 1984 a Hener Sorlar & Hener
APPROVED BY	TITLE	DATE	M. MILLENBACH
CONDITIONS OF APPROVAL, IF ANY:	网络教育 美元		M. MILLENBACH MANAGER AREA MANAGER

BUREAU OF LAND MANAGEMENT Caller Service 4104 Farmington, New Mexico 87499

Attachment to Notice of

Re: Permanent Abandonment

Intention to Abandon

Well: 12 Big Hit

CONDITIONS OF APPROVAL

- 1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal Leases."
- 2. The Farmington office (telephone (505) 325-4572) is to be notified in sufficient time for a representative to witness all plugging operations.
- 3. Blowout prevention equipment is required.
- 4. In addition to normal filling of pits and cleanup of location, additional surface restoration work may be required, i.e. ripping of pad and/or access road, reseeding, etc. We have asked the Surface Management Agency for the surface restoration requirements for this well and we should be able to furnish you these requirements within 30 days. After plugging the well and before making final clean-up, you should contact this office unless you have already been advised as to what additional surface restoration work is required.
- 5. The following modifications to your plugging program are to be made (when applicable):

A. Add a 100' cement plug from 3468' to 3368'

B. Add a 176' cement plug from 3330' to 3154

You are further advised that any instructions, orders or decisions issued by the Bureau of Land Management are subject to technical and procedural review pursuant to 43 CFR 3165.3 and appeal pursuant to 43 CFR 3165.4 and 43 CFR 4.700.

Office Hours: 7:45 A.M. to 4:30 P.M.

GENERAL REQUIREMENTS FOR PERMANENT ABANDONMENT OF WELLS ON FEDERAL LEASES FARMINGTON RESOURCE AREA

- 1. Secure prior approval before changing the approved plugging program.
- 2. Plugging equipment used shall have separate mixing and displacement pumps and a calibrated tank to assure proper displacement of plugs.
- 3. A proper tank or pit will be used to contain all fluids pumped from the well during plugging operations.
- 4. All cement plugs are to be placed through tubing (or drillpipe) and shall be a minimum of 15 sacks or 100 feet in length, whichever is greater.
- 5. Any cement plug placed when well is not full of fluid, or when well may be taking fluid, will be touched after cement has set to verify proper location.
- 6. Mud must be placed between plugs. Minimum consistency of plugging mud must be 9.2 lbs/gal. Brine is to be utilized for mixing mud where possible.
- 7. Within 30 days after plugging work is completed, file Subsequent Report of Abandonment, Form 3160-5 (formerly 9-331), in quintuplicate with Area Manager, Bureau of Land Management, Caller Service 4104, Farmington, New Mexico 87499. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. Show date well was plugged.
- 8. All permanently abandoned wells are to be marked with a permanent monument, on which has been stenciled or beaded the well name, well number, and well location by quarter-quarter, section, township and range. The monument is to be of steel pipe, not less than four inches in diameter, cemented permanently in the ground, and extending four feet above general ground level. The top should be closed with a screw cap, welding, or a cement plug.
- 9. After plugging work is completed:
 - a. Fill all pits, rat hole and cellar.
 - b. Clean well location of all equipment, concrete bases, pipe, junk and
 - c. Cut or remove tie downs.
- d. If last well on lease, and no additional drilling is contemplated, fill tank battery pits, remove battery equipment, and clean and level battery location.
- e. Accomplish surface restoration as specified by the surface management agency or land owner.

All above are minimum requirements. The Subsequent Report of Abandonment will not be approved and the period of liability under the bond of record terminated until the lease is inspected and surface work approved.

Please advise this office when the well location is ready for final inspection.

You are further advised that any instructions, orders or decisions issued by the Bureau of Land Management are subject to technical and procedural review pursuant to 43 CFR 3165.3 and appeal pursuant to 43 CFR 3165.4 and 43 CFR 4.700.