Form 3160-5 (June 1990)

Type of Well

Oil

2. Name of Operator

3. Address and Telephone No.

X Gas

UNITED STATES DEPARTMENT OF THE INTERIOR **BUREAU OF LAND MANAGEMENT**

| FORM | LAPPRO | OVED |
|------------|---------|-----------|
| Budget Bur | eau No. | 1004-0135 |
| Expires: | March 3 | 31, 1993 |

NM

5. Lease Designation and Serial No.

| J. | ic | Co | nt | 11 | ! |
|----|----|----|----|----|---|
| | | | | | |

Rio Arriba

SUNDRY NOTICES AND REPORTS ON WELLS 6. If Indian, Allottee or Tribe Name Do not use this form for proposals to drill or to deepen or reentry to a different reservoir. Jicarilla Apache Use "APPLICATION FOR PERMIT 7. If Unit or CA, Agreement Designation ALBUQUERQUE, N.M. SUBMIT IN TRIPLICATE 8. Well Name and No. Jicarilla 119N 10 ENERGEN RESOURCES CORPORATION 9. API Well No. 30-039-07134 2198 Bloomfield Highway, Farmington, NM 87401 10. Field and Pool, or exploratory Area 4. Location of Well (Footage, Sec., T., R., M., or Survey Description) Blanco MV 1585' FSL, 1050' FWL, Sec. 7, T26N, R4W, N.M.P.M. 11. County or Parish, State

| 2. | CHECK APPROPRIATE BOX(s) | TO INDICATE | NATURE OF NOTICE; PA | EPORT, OR O | THER DATA |
|----|--------------------------|-------------|--|-------------|---|
| | TYPE OF SUBMISSION | OF ACTION | | | |
| | X Notice of Intent | | Abandonment | | Change of Plans |
| | Subsequent Report | | Recompletion Plugging Back Casing Repair | | New Construction Non-Routine Fracturing Water Shut-Off |
| | Final Abandonment Notice | | Altering Casing Other | | Conversion to Injection Dispose Water |
| | | المحمدا | | | te: Report results of multiple completion on Well empletion or Recompletion Report and Log form.) |

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

It is intended to test the casing as follows:

- 1. MIRU, TOH.
- 2. TIH with packer & RBP. Set RBP at 4100'. Test casing to 500 psi. If no test isolate leak.
- 3. Squeeze cement with sufficient volume of cement to isolate leak.
- 4. TIH and clean out. Test casing to 500 psi. TOH retrieve RBP.
- 5. TIH and clean out to PBTD. Land tubing and return to production.

| I hereby certify that the foregoing is rue and correct Signed Oucca fall | Title Production Assistant | Date 8/11/00 |
|---|----------------------------------|--------------|
| (This space for Federal of the Grigory) W. Davis, Approved by Conditions of approval, if any: | Title Lands and Mineral Resource | AUG 3 0 2000 |

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction