

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPlicate*
(Other instructions on re-
verse side)Form approved
Budget Bureau No. 42-R1421

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐	5. LEASE DESIGNATION AND SERIAL NO. 14-20-693-1423
2. NAME OF OPERATOR Hixon Development Co.	6. IF INDIAN, ALLOTTEE OR TRIBE NAME No - Do - Not
3. ADDRESS OF OPERATOR 341 Milam Bldg San Antonio TX 78205	7. UNIT AGREEMENT NAME Central Bisti
4. LOCATION OF WELL (Report location clearly and in accordance with any state requirements. See also space 17 below.) 2000' FSL, 1700' FUL Sec. 3, T25N R12W SAN JOAN Co, N.M. NM PM	8. FARM OR LEASE NAME CBU
14. PERMIT NO.	9. WELL NO. 12
15. ELEVATIONS (Show whether BS, RT, OR, etc.) 6201 DF	10. FIELD AND POOL, OR WILDCAT Bisti Gallup
	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec 3, T25N, R12W NM PM
	12. COUNTY OR PARISH San Juan
	13. STATE N.M.

6. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF	☐	PULL OR ALTER CASING	☒
FRACTURE TREAT	☐	MULTIPLE COMPLETION	☐
SHOOT OR ACIDIZE	☐	ABANDON*	☒
REPAIR WELL	☐	CHANGE PLANS	☐
(Other)	☐		☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF	☐	REPAIRING WELL	☐
FRACTURE TREATMENT	☐	ALTERING CASING	☐
SHOOTING OR ACIDIZING	☐	ABANDONMENT*	☐
(Other)	☐		☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

This well is no longer capable of producing.
We intend to plug & abandon this well in the following manner:

1. Squeeze Perfs 4816-4910
2. Spot 10 cc plug inside 5 1/2" csg @ top of Point Lookout
3. Cut & Pull 5 1/2" Csg
4. Place Plug from 50' inside Stub to 50' Above Stub
5. Place 150' Plug over top of PC, 1117' to 967'
6. Cut Surface Pipe off 4' below Gnd Level
7. Place 105' plug intop of Surface Pipe.
8. Clean Loc.

18. I hereby certify that the foregoing is true and correct.

SIGNATURE Langford Redford TITLE Agent for Operator DATE June 5, 1974

(This space for Federal or State office use)

APPROVAL BY _____
CONDITIONS OF APPROVAL, IF ANY: _____

TITLE _____

*See Instructions on Reverse Side

