

NO. OF COPIES RECEIVED	6
DISTRIBUTION	
SANTA FE	1
FILE	1 ✓
U.S.G.S.	
LAND OFFICE	
OPERATOR	4

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
B-11240-60

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator El Paso Natural Gas Company	8. Farm or Lease Name Hamilton State
3. Address of Operator Box 990, Farmington, New Mexico	9. Well No. 8-X
4. Location of Well UNIT LETTER M , 879 FEET FROM THE South LINE AND 980 FEET FROM THE West LINE, SECTION 32 TOWNSHIP 26N RANGE 7W NMPM.	10. Field and Pool, or Wildcat Largo Canyon P. C.
15. Elevation (Show whether DF, RT, GR, etc.) 6959' DF	12. County Rio Arriba

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Due to non-commercial production it is intended to plug and abandon this well in the following manner:

1. Spot 30 sack cement plug down tubing to cover 2650' - 2877'.
2. Determine free point of the 5 1/2" casing. Shoot off casing at the free point. Spot 30 sack cement plug on 5 1/2" stub.
3. Put 10 sack plug in top of surface casing and install 4" x 4' plug and abandonment marker.

Note: If there is not enough casing free to be economically recovered, step #2 will be omitted.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original signed by
Carl E. Matthews

SIGNED _____ TITLE **Petroleum Engineer** DATE **10-4-66**

Original Signed by Emery C. Arnold SUPERVISOR DIST. #3
APPROVED BY _____ TITLE _____ DATE **OCT - 5 1966**

CONDITIONS OF APPROVAL, IF ANY: