

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name San Juan 27-5 Unit
8. Well No. 153
9. Pool name or Wildcat Basin Fruitland Coal <i>Tuffaco</i> <i>PC</i>

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER	
2. Name of Operator Meridian Oil Inc.	
3. Address of Operator P.O. Box 4239, Farmington, New Mexico 87499	
4. Well Location Unit Letter <u>E</u> : <u>1460'</u> Feet From The <u>North</u> Line and <u>1680'</u> Feet From The <u>West</u> Line Section <u>21</u> Township <u>27N</u> Range <u>05W</u> NMPM Rio Arriba County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 6561'	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well will be plugged in the following manner:

1. Fill casing with Class B neat cement from PBTD @ 3349' to 1572'.
2. Shoot 2 squeeze holes @ 1572' and 2 squeeze holes @ 176'.
3. SI Bradenhead valve then pump 85 sxs Class B neat cement down the casing. Open the Bradenhead and circulate cement to surface.
4. SI Bradenhead and then cut off wellhead and install permanent dry hole marker.
5. RDMO.

Received verbal approval from Charles Gholso on 9-13-90 at 3:00 p.m.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Michelle Little TITLE Drilling Technician DATE 9-13-90
TYPE OR PRINT NAME _____ TELEPHONE NO. _____

(This space for State Use)

APPROVED BY Original Signed by FRANK T. CHAVEZ TITLE SUPERVISOR DISTRICT # 3 DATE SEP 19 1990
CONDITIONS OF APPROVAL, IF ANY: