

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ gas ☒ other ☐
well well

2. NAME OF OPERATOR
Southland Royalty Company

3. ADDRESS OF OPERATOR
P.O. Drawer 570, Farmington, NM 87499

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 1840' FSL & 1000' FEL
AT TOP PROD. INTERVAL:
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
CHANGE ZONES ☐
ABANDON* ☒
(other)

SUBSEQUENT REPORT OF:

☐
☐
☐
☐
☐
☐
☐
☐
☐
☐

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

RECEIVED
OCT-6 1983

OIL CON. DIV.
DIST. 3

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

SOUTHLAND ROYALTY COMPANY hereby proposes to plug and abandon the subject well in the following manner:

- 1) MIRU Completion Unit. POOH with 2-3/8" tubing. Check for bad joints.
- 2) TIH with 2-3/8" tubing open-ended. Spot 45 sacks (53 cu.ft.) at 3757'. Squeeze 25 sacks cement into perforations.
- 3) POOH with 2-3/8" tubing.
- 4) Rig up casing jacks pull stretch on 7" casing to find freepoint, shoot casing of 50' \pm freepoint (Top of Cement at 2700' \pm). POOH and lay down 7" casing.

CONTINUED OTHER SIDE

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED [Signature] TITLE PE DATE 9-28-83

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

Add 100' plug 3440' to 3340' to cover the bottom of the Ojo Alamo.

*See Instructions on Reverse Side

NMOCC

APPROVED
AS AMENDED

OCT 04 1983

M. MILLENBACH
AREA MANAGER