

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5. LEASE DESIGNATION AND SERIAL NO. SF-078897
2. NAME OF OPERATOR El Paso Products Company		6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR P. O. Box 1560, Farmington, New Mexico		7. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 660'N, 1980'E, 26N, 11W		8. FARM OR LEASE NAME Western
14. PERMIT NO.		9. WELL NO. 5
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 6098'GL		10. FIELD AND POOL, OR WILDCAT Gallegos Gallup
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA 7, 26N, 11W
		12. COUNTY OR PARISH San Juan
		13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
(Other) ☐

PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
ABANDON* ☒
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐
FRACTURE TREATMENT ☐
SHOOTING OR ACIDIZING ☐
(Other) ☐

REPAIRING WELL ☐
ALTERING CASING ☐
ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

(Est. date to start work
4-1-68)

1. Load hole with mud laden fluid.
2. Squeeze Gallup perforations.
3. Shoot pipe loose at free point and pull.
4. Spot 100' cement plug 50' in and 50' out of stub.
5. Spot 100' cement plug across top of picture cliff.
6. Spot 100' cement plug at base of Ojo Alamo.
7. Place cement plug in top of surface with welded marker in place.
8. Clean location.



RECEIVED

MAR 29 1968

U. S. GEOLOGICAL SURV
FARMING

18. I hereby certify that the foregoing is true and correct

SIGNED John Payne TITLE Agent DATE 3-20-68

(This space for Federal or State office use)

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY: