

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on reverse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

SF-078897

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Western

9. WELL NO.

3

10. FIELD AND POOL, OR WILDCAT

Gallegos Gallup

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

7. 26N. 11W

12. COUNTY OR PARISH 13. STATE

San Juan New Mexico

1. OIL WELL ☒ GAS WELL ☐ OTHER

2. NAME OF OPERATOR

El Paso Products Company

3. ADDRESS OF OPERATOR

P. O. Box 1560, Farmington, New Mexico

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

14. PERMIT NO. 660'N, 660W, 26N, 11W

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

6048' GL

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

(Est. date to start work
4-1-68)

1. Load hole with mud laden fluid.
2. Squeeze Gallup perforations.
3. Shoot pipe loose at free point and pull.
4. Spot 100' cement plug 50' in and 50' out of stub.
5. Spot 100' cement plug across top of picture cliff.
6. Spot 100' cement plug at base of Ojo Alamo.
7. Place cement plug in top of surface with welded marker in place.
8. Clean location.



RECEIVED

MAR 29 1968

U. S. GEOLOGICAL SURV

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Agent

DATE

3-20-68

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side