

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

NEW MEXICO OIL CONSERVATION COMMISSION

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

5a. Indicate Type of Lease State <input type="checkbox"/> Federal <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name Huerfano Unit
2. Name of Operator El Paso Natural Gas Company	8. Farm or Lease Name Huerfano Unit
3. Address of Operator Box 990, Farmington, New Mexico	9. Well No. 10
4. Location of Well UNIT LETTER G , 1650 FEET FROM THE North LINE AND 1650 FEET FROM THE East LINE, SECTION 6 TOWNSHIP 26N RANGE 10W NMPM.	10. Field and Pool, or Wildcat West Kutz P. C.
15. Elevation (Show whether DF, RT, GR, etc.) 6580' DF	12. County San Juan

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Due to non-commercial production it is planned to plug and abandon this well in the following manner:

Set ~~as~~ a cast iron cement retainer near the bottom of the 5 1/2" casing, approximately 2090', squeeze the open hole w/75 sacks of Class C cement w/2% gel.

It is not intended to recover any of the 5 1/2" casing.

* Squeeze 20 sacks cement thru perforations at 1750
Put a 10 sack cement plug and 4" x 4' plug and abandonment marker in the top of the surface casing.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Original signed by
Carl E. Matthews

TITLE **Petroleum Engineer**

DATE **10-10-67**

APPROVED BY *Emory C. Lewis*
CONDITIONS OF APPROVAL, IF ANY:

TITLE **SUPERVISOR DIST. #3**

DATE **OCT 11 1967**