

BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals.)

1. ☐ OIL WELL ☐ GAS WELL ☐ OTHER Disposal Well		2. NAME OF OPERATOR Reading & Bates Petroleum Co.		3. ADDRESS OF OPERATOR 3200 Mid-Continent Tower		4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. ^a See also space 17 below.) At surface 1763'FSL 977'FWL		5. LEASE DESIGNATION AND SERIAL NO. 14-20-603-5019		6. IF INDIAN, ALLOTTEE OR TRIBE NAME Navajo		7. UNIT AGREEMENT NAME		8. FARM OR LEASE NAME Navaio Tocito		9. WELL NO. 4		10. FIELD AND POOL, OR WILDCAT Tocito Dome		11. SEC., T., R., N., OR B.E. AND SURVEY OR AREA 10-T26N-R18W		12. COUNTY OR PARISH San Juan		13. STATE NM	
14. PERMIT NO.				15. ELEVATIONS (Show whether SP, TV, GR, etc.) 5105 GL																					

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Procedure to P&A

1. Set CIBP @ 6332'
2. Set 50' cement plug on CIBP from 6282'-6332'.
3. Shoot squeeze holes & set plug from 3460'-3560'.
4. Shoot squeeze holes & set plug from 2498'-2598'.
5. Shoot squeeze holes & set plug from 1624'-1724'.
6. Shoot squeeze holes & set plug from 1090'-1190'.
7. Shoot squeeze holes & set plug from 724'-824'.
8. Shoot squeeze holes & set plug 143'-surface.

9.2# mud or greater between plugs.

→ Set 100' cement plug from 5413-5513

RECEIVED
JAN 28 1988
OIL CON. DIV.
DIST. 3

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Sr. Engineer Technician

DATE 1-20-88

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

111000

APPROVED
AS AMENDED

JAN 26 1988

AREA MANAGER

*See Instructions on Reverse Side

1940

1940
COLUMBIA 24
BOSTON
1940

24