

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

080505-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL GAS WELL OTHER

2. NAME OF OPERATOR

El Paso Natural Gas Company

3. ADDRESS OF OPERATOR

PO Box 990, Farmington, NM 87401

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface 1600'S, 990'W

7. UNIT AGREEMENT NAME

San Juan 28-6 Unit

8. FARM OR LEASE NAME

San Juan 28-6 Unit

9. WELL NO.

20

10. FIELD AND POOL, OR WILDCAT

Blanco Mesa Verde

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 12, T-28-N, R-6-W

NMPM

12. COUNTY OR PARISH 13. STATE

Rio Arriba NM

14. PERMIT NO.

15. ELEVATIONS (Show whether DP, RT, GR, etc.)

6560'GL

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF
FRACTURE TREAT
SHOOT OR ACIDIZE
REPAIR WELL
(Other)
PULL OR ALTER CASING
MULTIPLE COMPLETE
ABANDON*
CHANGE PLANS

WATER SHUT-OFF
FRACTURE TREATMENT
SHOOTING OR ACIDIZING
(Other)
REPAIRING WELL
ALTERING CASING
ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

It is planned to plug and abandon this well in the following manner:

Cut off tubing near 7" casing shoe and pull.
Set retainer and squeeze the open hole with 150 sks. of cement.
Locate hole in casing with packer. Set cement retainer and squeeze leak with 100 sks. of cement. Leave 100' cement plug below retainer.
If the casing leak is not near the base of the Ojo Alamo, it will be necessary to perforate at 2830' and squeeze with 100 sks. of cement.
Pump 75 sks. of cement down bradenhead.
Spot a cement surface plug with 4' x 4" Plug and Abandonment marker.
Clean up and level location.

(as per my conversation with Jerry Long this date)

RECEIVED

OCT 28 1975

U. S. GEOLOGICAL SURVEY
DURANGO, COLO.

RECEIVED
OCT 29 1975
OIL CON. COM.
DIST. 3

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Division Drilling Engr

10-23-75

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

LA