

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE\*  
(Other instructions on re-  
verse side)

Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

SF-080382

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT--" for such proposals.)

1.

OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

Aztec Oil & Gas Company

3. ADDRESS OF OPERATOR

P.O. Drawer 570, Farmington, New Mexico 87401

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*

See also space 17 below.)  
At surface

990' FNL - 1650' FWL

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Schwerdtfeger

9. WELL NO.

#2

10. FIELD AND POOL, OR WILDCAT

West Kutz Pictured Cliffs

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Section 28, T27N, R11W

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

6345' DF

12. COUNTY OR PARISH

San Juan

13. STATE

New Mexico

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON\* ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT\* ☐

(Note: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

PURPOSE TO:

Pull 1" tubing.

Spot 100' cement plug in 5½" casing (50' inside pipe, 50' in open hole).

Determine free point, shoot 5½" casing off above free point.

Spot 50' cement plug on stub.

Spot 50' cement plug across 8-5/8" casing shoe.

Spot 15 sacks cement at surface.

Install dry hole marker, level location.

RECEIVED

AUG 24 1977

U. S. GEOLOGICAL SURVEY  
FARMINGTON, N.M.

18. I hereby certify that the foregoing is true and correct

SIGNED

*Charles E. ...*

TITLE

District Engineer

DATE

August 24, 1977

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: