

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT - " for such proposals

1. Type of Well <input type="checkbox"/> Oil Well <input type="checkbox"/> Gas Well <input checked="" type="checkbox"/> Other Cathodic Protection		5. Lease Designation and Serial No. SF 077085
2. Name of Operator Amoco Produccion Company		6. If Indian, Allottee or Tribe Name
3. Address and Telephone No. P.O. Box 800, Denver, Colorado 80201		7. If Unit or CA, Agreement Designation
4. Location of Well (Footage, Sec., T., R., M., or Survey Description) 790FNL 1850FEL Sec. 26 T 28N R 10W		8. Well Name and No. Omler "A" 17
		9. API Well No. 3004525539
		10. Field and Pool, or Exploratory Area Harris Mesa Ext.
		11. County or Parish, State San Juan New Mexico.

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA	
TYPE OF SUBMISSION	TYPE OF ACTION
<input checked="" type="checkbox"/> Notice of Intent <input type="checkbox"/> Subsequent Report <input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Abandonment <input type="checkbox"/> Recompletion <input type="checkbox"/> Plugging Back <input type="checkbox"/> Casing Repair <input type="checkbox"/> Altering Casing <input checked="" type="checkbox"/> Other P & A Cathodic well <input type="checkbox"/> Change of Plans <input type="checkbox"/> New Construction <input type="checkbox"/> Non-Routine Fracturing <input type="checkbox"/> Water Shut-Off <input type="checkbox"/> Conversion to Injection <input type="checkbox"/> Dispose Water
(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)	

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)
Amoco Production Company request permission to Plug & Abandon the above mentioned Cathodic well .

See Attached Procedures

If you have any questions please contact Mark Rothenburg @ (303) 830-5612

RECEIVED
FEB 24 1995
OIL & GAS
BUREAU

14. I hereby certify that the foregoing is true and correct
Signed *Lois Raeburn* Title Business Assistant Date 01-23-1995
(This space for Federal or State office use)

Approved by _____ Title _____ Date **APPROVED**
Conditions of approval, if any: _____ **FEB 08 1995**

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent representations as to any matter within its jurisdiction.

Ground Bed Abandonment Procedures

Well Name: Omler A 17

Location: B26-29N-10W

1. Weld 6" dia. spool with diverter line to pit
2. MIRU
3. Wash in hole with 1 1/4" work string. Circulate out coke breeze. Pull anodes as they come free. Wash hole to 300' (or TD).
4. Pump adequate cement to partially fill hole. Pull out work string.
5. Top off hole with cement. Set flexible pipeline marker as PxA marker.
from the top of the 1st cement plug.
6. RDMO

Ground Bed Specifications

TD: 300' (approx)

Hole Dia.: unknown

Casing Dia.: unknown

Casing Length: unknown

1/6/95 mdr