Form 9-331

## HNITED STATES

Form approved.

(May 1963			OR verse side)	5. LEASE DESIGNATION AND SERIAL NO. I-149-IND-8470	
SUNDRY NOTICES AND REPORTS ON WELLS  (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  Use "APPLICATION FOR PERMIT" for such proposals.)				6. If INDIAN, ALLOTTEE OR TRIBE NAME Navajo Tribe	
1.  OIL X CAS WELL OTHER  2. NAME OF OPERATOR Amoco Production Company - operator				7. UNIT AGREEMENT NAME Gallegos Canyon Unit 8. FARM OR LEASE NAME	
		& Gas Company - sub		Gallup Part. Area "gr	
Amoco - Security Life Building, Denver, Colorado 80202.  Aztec - 2000 First National Bank Building, Dallas, Texas 75202  4. Location of Well (Report location clearly and in accordance with any State requirements.*  See also space 17 below.)  At surface				9. WELL NO. 129 10. FIELD AND POOL, OR WILDCAT Cha Cha Gallup	
660' NL, 1960' WL, Section 30-28N-12W Unit Letter C				11. SEC., T., R., M., OR DUK. AND SURVEY OR AREA  Sec. 30-T28N-R12W	
14. PERMIT NO. 15. ED VATIONS (Show whether DF, RT, GR, etc.)			12. COUNTY OR PARISH 13. STATE		
		5758' КВ		San Juan New Mexico	
16.	Check Appropriate Box To Indicate Nature of Notice, Report, or C			Other Data	
	NOTICE OF INTEN	rion to:	subsec	QUENT REPORT OF:	
TEST WATER SHUT-OFF PULL OR ALTER CASING PRACTURE TREAT  SHOOT OR ACIDIZE  REPAIR WELL  (Other)  PULL OR ALTER CASING MULTIPLE COMPLETE  ABANDON*  X  SHOOTING OR ACIDIZING  (Other)  (Note: Report result Completion or Recom			BEPAIRING WELL  ALTERING CASING  ABANDONMENT*  Its of multiple completion on Well pletion Report and Log form.)		
nen Sjta	t to this work.)* itus: 8-5/8" surfa l'/15'. Perf Depleted oil	ce pipe at 200'. Bas orations 5453-57'. L well.	se Ojo Alamo estimat		
Propose to plug well as follows:					
1.	7. 2. 7. 7. 7. 7. 7. 7. 7. 7. 7. 7. 7. 7. 7.				
2.	Place 10 sxs. cement (130') plug from 1780' to 1650'				
3.	Cut 4-1/2" casing at free point (top of annular cement calculated 477') and pull same. Fill hole with gel-mud. Place 30 sxs. cement (160') plug bottomed 75' below casing cut.				
4.	Place 30 sxs. cement (100') plug from 250' to 150'				
5.	Place 30 sxs. cement (37') plug in top of surface pipe.			한 환경 보는 경우를 보고 함께 하는 것이다.	
6.	Cut off pipe at bottom of cellar, place one sack cement on top of pipe and install regulation marker.				
7.	Clean up and level location to as near original contour as practicable.				
	AMOCO PRODUCTION CO		a 0	울리하다는 경험 원인원이	
18. I here	by certify that the foregoing is	true and correct		7	