

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

EXPIRATION DATE
THIS INFORMATION ON REVERSE

LEAVE DESIGNATION AND FIELD NO.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

SF077968

6. IF INDIAN, ALLOTTEE OR TRUST NAME

7. UNIT AGREEMENT NAME

S. E. Cha Cha

8. FARM OR LEASE NAME

9. WELL NO.

18

10. FIELD AND POOL, OR WILDCAT

Cha Cha Gallup

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 16, T28N, R13W

12. COUNTY OR PARISH 13. STATE

San Juan

NM

RECEIVED

JAN 30 1986

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Hicks Oil & Gas, Inc.

3. ADDRESS OF OPERATOR

P.O. Drawer 3307 - Farmington, New Mexico 87499

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.)

See also space 17 below.
At surface

2040' FNL and 510' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

6078' DF

BUREAU OF LAND MANAGEMENT
FARMINGTON RESOURCE AREA

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETION

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT*

(Other)

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to plug and abandon this well as follows:

1. Clean out to 4741' and spot cement inside and outside of casing from 4741' to 4015'.
2. Perforate casing at 2686'. Spot cement inside and outside of casing from 2686' to 2586'. Top of Mesa Verde at 2636'.
3. Perforate casing at 1782'. Spot cement inside and outside of casin from 1782' to 1255'. Top of P.C. 1732'. Top of Fruitland 1305'.
4. Perforate casing at 394'. Pull 4½ casing from 394'. Spot cement plug from 394' to surface. Erect dry hole marker.

RECEIVED
MAR 03 1986
OIL CON. DIV.
DIST. 3

I hereby certify that the foregoing is true and correct

SIGNED

Mike Hicks

TITLE President/Hicks Oil & Gas

DATE

1-24-86

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

APPROVED
AS AMENDED
DATE

FEB 28 1986

M. MILLENBACH
AREA MANAGER

*See Instructions on Reverse Side

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

BUREAU OF LAND MANAGEMENT
Drawer 600
Farmington, New Mexico 87499-00600

Attachment to Notice of
Intention to Abandon

Re: Permanent Abandonment
Well: 18 S.E. Cha Cha

CONDITIONS OF APPROVAL

1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal Leases."
2. The Farmington office (telephone (505) 325-4572) is to be notified in sufficient time for a representative to witness all plugging operations.
3. Blowout prevention equipment is required.
4. In addition to normal filling of pits and cleanup of location, additional surface restoration work may be required, i.e. ripping of pad and/or access road, reseeding, etc. We have asked the Surface Management Agency for the surface restoration requirements for this well and we should be able to furnish you these requirements within 30 days. After plugging the well and before making final clean-up, you should contact this office unless you have already been advised as to what additional surface restoration work is required.
5. The following modifications to your plugging program are to be made (when applicable):

- a. Add a cement plug from 3328' to 3228' inside and outside of casing to cover the top of the Mesa Verde formation.
- b. The plug in item 4 is to be extended down hole to 462' in order to cover the bottom of the Ojo Alamo.

Note: The plug proposed in item 2 will be satisfactory to cover the top of the Chaco formation.

Office Hours: 7:30 A.M. to 4:15 P.M.

GENERAL REQUIREMENTS FOR
PERMANENT ABANDONMENT OF WELLS ON FEDERAL LEASES
FARMINGTON DISTRICT

1. Secure prior approval before changing the approved plugging program.
2. Plugging equipment used shall have separate mixing and displacement pumps and a calibrated tank to assure proper displacement of plugs.
3. A proper tank or pit will be used to contain all fluids pumped from the well during plugging operations.
4. All cement plugs are to be placed through tubing (or drillpipe) and shall be a minimum of 25 sacks or 100 feet in length, whichever is greater.
5. Any cement plug placed when well is not full of fluid, or when well may be taking fluid, will be touched after cement has set to verify proper location.
6. Mud must be placed between plugs. Minimum consistency of plugging mud must be 9.2 lbs/gal. Brine is to be utilized for mixing mud where possible.
7. Within 15 days after plugging work is completed, file Subsequent Report of Abandonment, form 9-331, in quintuplicate with District Supervisor, U.S.G.S., Drawer 600, Farmington, New Mexico 87499-00600. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. Show date well was plugged.
8. All permanently abandoned wells are to be marked with a permanent monument, on which has been stenciled or beaded the well name, well number, and well location by quarter-quarter, section, township, and range. The monument is to be of steel pipe, not less than four inches in diameter, cemented permanently in the ground, and extending four feet above general ground level. The top should be closed with a screw cap, welding, or a cement plug.
9. After plugging work is completed:
 - a. Fill all pits, rat hole and cellar.
 - b. Clean well location of all equipment, concrete bases, pipe, junk and trash.
 - c. Cut or remove tie downs.
 - d. If last well on lease, and no additional drilling is contemplated, fill tank battery pits, remove battery equipment, and clean and level battery location.
 - e. Accomplish surface restoration as specified by the surface management agency or land owner.

All above are minimum requirements: The Subsequent Report of Abandonment will not be approved and the period of liability under the bond of record terminated until the lease is inspected and surface work approved.

Please advise this office when the well location is ready for final inspection.