UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED Budget Bureau No. 1004-0135 Expires: March 31, 1993

DUKEAU UF LAND MANAGEMENT	
SUNDRY NOTICES AND REPORTS ON WELLS	5. Lease Designation and Serial No.
Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.	SF - 078414
Use "APPLICATION FOR PERMIT " for such proposals	6. If Indian, Allottee or Tribe Name
575	
	7. If Unit or CA, Agreement Designation
MAR 2000	
1. Type of Well	
Well Other C C C C C C C C C C C C C C C C C C C	8. Well Name and No.
2. Name of Operator AMOCO PRODUCTION COMPANAC DIST. 3 May Corley	Day A LS 14
3. Address and Telephone No.	30-045-20907
P.O. BOX 3092 HOUSTON, TX 772582 / #1000 ft 8 281-366-4491	10. Field and Pool, or Exploratory Area
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)	Blanco (Pictured Cliffs)
47 7 991 2 911	11. County or Parish, State
1650' FNL 1650' FEL Sec. 17 T 29N R 8W UNIT G	SAN JUAN NEW MEXICO
12 CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPO	DRT, OR OTHER DATA
TYPE OF SUBMISSION TYPE OF ACTION	
Abandonment	Ob and Ob
Notice of Intent Recompletion	Change of Plans New Construction
Plugging Back	Non-Routine Fracturing
Subsequent Report Casing Repair Altering Casing	Water Shut-Off Conversion to Injection
Final Abandonment Notice SIM LTR 9/10/1999	Dispose Water
(Note: Report res	ults of multiple completion on Well Completion or Recompletion Report and Log form.
13. Describe Proposed or Complisted Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work . If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*	
Amoco Production Company request permission to plug and abandon the subject well as follows:	
 Notify regulatory agencies (BLM, NMOCD, FIMO) 24 hours in advance of plugging activity. Contact BLM and indicate well is allotted (FIMO regulations effective April 1, 1997). 	
2. Rigless operation. Blow down well.	
3. Run CBL to determine cement top. Bullhead Class B neat cement down casing to abandon PC. Wait on cement 3 hours. Perforate squeeze holes at cement top. Pump down casing and circulate cement to surface. Use 65:35 POZ and tail in with 100 sacks Class B neat cement leaving casing full of cement.	
Cut off casing and wellhead. Install PXA marker according to BLM or state requirements.	
5. Contact FMC and ship surface equipment to yard or other location per instructions.	
6. Provide workorder to Buddy Shaw for reclamation.	
7. Rehabilitate location according to BLM or State requirements.	
14. I hereby certify that the foregoing jeft of any correct	
Signed May Welly Title Sr. Business And	alyst 02-10-2000
(This space for Faderal or State office use)	
/s/ Charlie Beecham Teem Lead, Petroleum M	MAR 1 3 2000
Approved by Title Conditions of approvel, if any:	Oate

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, ficticious, or fraudulent statements or representations as to any matter within its jurisdiction.