

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name
8. Farm or Lease Name State Gas Com "A"
9. Well No. 1
10. Field and Pool, or Wildcat Blanco Mesaverde
12. County San Juan

SUNDY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-
2. Name of Operator AMOCO PRODUCTION COMPANY
3. Address of Operator 501 Airport Drive Farmington, NM 87401
4. Location of Well UNIT LETTER <u>A</u> <u>990</u> FEET FROM THE <u>North</u> LINE AND <u>990</u> FEET FROM THE <u>East</u> LINE, SECTION <u>16</u> TOWNSHIP <u>29N</u> RANGE <u>9W</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 5876' GL, 4835' PBD

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <u>Revised P & A Proposal</u> <input checked="" type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/> CHANGE PLANS <input type="checkbox"/> REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOBS <input type="checkbox"/> OTHER <input type="checkbox"/>
17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.	

Amoco Production Company proposes to plug and abandon the above well in the following manner:

- 1) MIRU service unit, pull tubing and kill well
- 2) Spot plugs using Class "B" Neat cement as follows:
 - a) Spot 100 sx across Mesaverde from TD to 4000'
 - b) Spot 25 sx across Pictured Cliffs from 2350-2550'
 - c) Spot 15 sx across Ojo Alamo from 1845-1955'
 - d) Spot 15 sx from 110' to surface
- 3) Remove wellhead and install P & A marker
- 4) Clean up location

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED E. E. SVOBODA TITLE Dist. Adm. Supvr. DATE 8/21/79

APPROVED BY [Signature] TITLE DATE 8 22 1979

CONDITIONS OF APPROVAL, IF ANY: