

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State ☐ Federal ☒

5. State Oil & Gas Lease No.

<p align="center"><b>SUNDRY NOTICES AND REPORTS ON WELLS</b> (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)</p>		
1. OIL <input type="checkbox"/> WELL GAS <input checked="" type="checkbox"/> WELL OTHER	2. Name of Operator El Paso Natural Gas Company	7. Unit Agreement Name San Juan 30-5 Unit
3. Address of Operator PO Box 990, Farmington, NM 87401		8. Form or Lease Name San Juan 30-5 Unit
4. Location of Well UNIT LETTER <u>A</u> <u>990</u> FEET FROM THE <u>North</u> LINE AND <u>250</u> FEET FROM THE <u>East</u> LINE, SECTION <u>30</u> TOWNSHIP <u>30N</u> RANGE <u>5W</u> NMPM.		9. Well No. 5
	10. Field and Pool, or Wildcat Blanco Mesa Verde	
11. Elevation (Show whether DF, RT, GR, etc.) 6229'GL	12. County Rio Arriba	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Due to non-commerical production it is planned to plug and abandon this well as follows:

Spot a 50 sk. cement plug across the perforated interval (5102-5614').

Shoot off 5" casing at free point and spot a 50 sks. cement plug on the casing stub, pull casing.

Shoot off 7" casing at free point and spot a 50 sks. cement plug on the casing stub, pull casing.

Spot a 25 sks. cement plug at the base of the surface casing.

Place a 15 sks. cement plug at the surface with a Plug and Abandonment marker. Clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Original Signed E. H. WOOD TITLE Petroleum Engineer DATE January 20, 1972

APPROVED BY Emmy Cleared TITLE  DATE JAN 20 1972  
CONDITIONS OF APPROVAL, IF ANY: