

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

MN 019407

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME *S&B*~~George E. Willett~~

9. WELL NO.

#23DD-Federal

10. FIELD AND POOL, OR WILDCAT

*Jal West Kutz DC*11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec 31, T29N, R11W.

12. COUNTY OR PARISH 13. STATE

San Juan

N.M.

SUNDRY NOTICES AND REPORTS ON WELLS
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)1. OIL ☐ GAS ☐ OTHER ☒ Dry Hole
WELL WELL

2. NAME OF OPERATOR

George E. Willett

3. ADDRESS OF OPERATOR

P.O. Box 548, Lemoore, California 93245

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See also space 12 below.)
At surface

1190 ft. From South Line

790 ft. From West Line

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, OR, etc.)

5447 ft. Ground; 5460 ft. KB

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.) *

Request permission to plug and abandon.

Total Depth -- 1720'; Plugback - 1720 to 1200 ft.

4½" casing cemented top to bottom.

Plugging program: -

Set plugs 1200' to 800' -- Fruitland and Lower Farmington ss.

350' to 150' -- Ojo Alamo ss.

Top hole plug.

Procedures -- Tag bottom- Load hole with water - Set Bottom plug -
Set Intermediate plug - Cut off casing about 5' below surface - Set Top hole plug - Clear and
level location - No marker to be set.

18. I hereby certify that the foregoing is true and correct

SIGNED *Lee W. Kilgore*

TITLE Agent

DATE Oct. 27, 1971

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

*See Instructions on Reverse Side

