

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other Instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

SF 0787-1

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1.

OIL ☐ GAS ☒ OTHER

2. NAME OF OPERATOR

Northwest Pipeline Corporation

3. ADDRESS OF OPERATOR

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

990' FNL & 990' FEL

7. UNIT AGREEMENT NAME

San Juan 30-5

8. FARM OR LEASE NAME

San Juan 30-5

9. WELL NO.

#1

10. FIELD AND POOL, OR WILDCAT

Blanco Mesa Verde

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 22, T30N, R5W NMPM

12. COUNTY OR PARISH

Rio Arriba

13. STATE

N.M.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

6675'

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐
(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Due to non-commercial production we propose to plug and abandon this well in the following manner:

1. Circulate well and spot cement plug in open hole and across 7" casing shoe.
2. Perforate squeeze holes at base of Pictured Cliffs and Ojo Alamo. Squeeze with 70 sacks each. Determine free point of 7" casing. Shot 7" casing off above free point and spot cement plug on stub.
3. Spot cement plug across 10 3/4" casing shoe.
4. Place 10 sacks at surface with 4" X 4' dry hole marker.



18. I hereby certify that the foregoing is true and correct

SIGNED

R. E. Fielder

TITLE

Prod. Engr.

DATE

10/30/75

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

St.

*See Instructions on Reverse Side