DEPARTME BUREAU OF  SUNDRY NOTICES  Do not use this form for proposals to a	SITED STATES ENT OF THE INTERIOR E LAND MANAGEMENT  S AND REPORTS ON WELLS drill or to deepen or reentry to a different reservoir.	FORM APPROVED  Budget Bureau No. 1004-0135  Expires: March 31, 1993  5. Lease Designation and Serial No.  14-20-603-2168A  6. If Indian, Allottee or Tribe Name
Tor such proposals		Navajo Nation 7. If Unit or CA, Agreement Designation
SUBMIT IN TRIPLICATE  1. Type of Well Oil Well Well Other		NW Cha Cha Unit
2. Name of Operator  MOUNTAIN STATES PETROLEUM CORP.  3. Address and Telephone No.		8. Well Name and No.  NW Cha Cha Unit 36  9. API Well No.
P O BOX 3531, MIDLAND, TX 79702 915/685-0878  Location of Well (Footage, Sec., T., R., M., or Survey Description)  660' FNL & 660' FEL Sec., 28, T29N, R14W, NMPM		30-045-07924  10. Field and Pool, or Exploratory Area Cha Cha Gallup  11. County or Parish, State San Juan, NM
CHECK APPROPRIATE BOX	(s) TO INDICATE NATURE OF NOTICE, REPOR	RT, OR OTHER DATA
TYPE OF SUBMISSION  Notice of Intent	TYPE OF ACTION	
Subsequent Report  Final Abandonment Notice	Abandonment  Recompletion  Plugging Back  Casing Repair  Altering Casing  Other	Change of Plans  New Construction  Non-Routine Fracturing  Water Shut-Off  Conversion to Injection  Dispose Water
	pertinent details, and give pertinent dates, including estimated date of starting all depths for all markers and zones pertinent to this work.)*	
We request approval to pluthe attached procedure.	ng and abandon this well in acco	. 2
Plugging will be co	impleted by July 1, 1997.	RECEI 97 APR -1

DECEIVED N APR - 9 1897 PH 4: 18

@[[] G@M. DFV.

14. I hereby certify that the foregoing is true and correct	DISIL 3	
Signed Ricer th. new	Tide_ Agent	Date 4/1/97
(This space for Federal or State office use)		Date
Approved by Sponson Conditions of approval, if any:	Tide	Date APR - 7 1997

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

## NW CHA CHA UNIT SAN JUAN COUNTY, NEW MEXICO

## PROCEDURE TO P&A WELL NO. 36

- 1. Move in & rig up pulling unit
- 2. Set bridge plug 50' above top perf
- 3. Spot cement to 50' above Gallup
- 4. Shoot casing and recover casing
- 5. Set plug in and out of top of casing, 100' plug w/25 sx cement
- 6. Set 100' plug w/30 sx cement across Cliffhouse formation
- 7. Set 100' plug w/30 sx cement across Fruitland/Picture Cliffs formation
- 8. Set 25 sx cement plug at surface
- 9. Install dry hole marker