

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-73

| | |
|------------------------|--|
| NO. OF COPIES RECEIVED | |
| DISTRIBUTION | |
| SANTA FE | |
| FILE | |
| U.S.O.S. | |
| LAND OFFICE | |
| OPERATOR | |

5a. Indicate Type of Lease
State ☐ Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

| | |
|--|---|
| 1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- | 7. Unit Agreement Name |
| 2. Name of Operator Flag-Redfern Oil Company | 8. Farm or Lease Name McCarty |
| 3. Address of Operator P O Box 208, Farmington, NM 87499 | 9. Well No. 1 |
| 4. Location of Well UNIT LETTER <u>M</u> <u>970</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>28</u> TOWNSHIP <u>30N</u> RANGE <u>12W</u> N.M.P.M. | 10. Field and Pool, or Wildcat Fulcher Kutz-P.C. |
| 15. Elevation (Show whether DF, RT, GR, etc.) | 12. County San Juan |

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

| | | | |
|--|--|--|---|
| PERFORM REMEDIAL WORK <input type="checkbox"/> | PLUG AND ABANDON <input checked="" type="checkbox"/> | REMEDIAL WORK <input type="checkbox"/> | ALTERING CASING <input type="checkbox"/> |
| TEMPORARILY ABANDON <input type="checkbox"/> | CHANGE PLANS <input type="checkbox"/> | COMMENCE DRILLING OPNS. <input type="checkbox"/> | PLUG AND ABANDONMENT <input type="checkbox"/> |
| PULL OR ALTER CASING <input type="checkbox"/> | OTHER <input type="checkbox"/> | CASING TEST AND CEMENT JOBS <input type="checkbox"/> | OTHER <input type="checkbox"/> |

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1503.

Plan to plug and abandon well as follows:

- 1.) Rig up, pull and inspect tubing.
- 2.) Set 100' bottom plug with tubing string.
- 3.) Set 100' plug separating the Fruitland and Farmington formations (13.3 c.f.). *IN + OUT*
- 4.) Set 200' plug across Ojo Alamo (27 c.f.). *IN + OUT*
- 5.) Set 20 sx plug at surface (23 c.f.).
- 6.) Set dry hole monument.
- 7.) Clean and restore location.

JAN 20 1987
OIL CON. DIV.
DIST. 3

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

| | | |
|--|--------------------------------------|-------------------------|
| SIGNED <u>Sherman E. Dugan</u> Sherman E. Dugan | TITLE <u>Geologist</u> | DATE <u>1-19-87</u> |
| APPROVED BY <u>Charles G. Hobson</u> | DEPUTY OIL & GAS INSPECTOR, DIST. #3 | DATE <u>JAN 20 1987</u> |

CONDITIONS OF APPROVAL, IF ANY: