

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Federal <input type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-	7. Unit Agreement Name San Juan 32-9 Unit NP
2. Name of Operator El Paso Natural Gas Company	8. Farm or Lease Name San Juan 32-9 Unit NP
3. Address of Operator PO Box 990, Farmington, NM 87401	9. Well No. 10
4. Location of Well UNIT LETTER G 1628 FEET FROM THE North LINE AND 1634 FEET FROM THE East LINE, SECTION 34 TOWNSHIP 32N RANGE 9W NMPM.	10. Field and Pool, or Wildcat Blanco Mesa Verde
15. Elevation (Show whether DF, RT, GR, etc.) 6610'GL	12. County San Juan

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Due to non-commercial production it is planned to plug and abandon this well as follows:

Spot a 50 sk. cement plug to fill open hole (5736-5956').

Perforate squeeze hole at base of the Ojo Alamo and squeeze with 50 sks. cement leaving 20 sks. inside casing.

Shoot off 7" casing at free point and spot a 50 sks. cement plug on the casing stub, pull casing.

Spot a 25 sks. cement plug at the base of the surface casing.

Place a 15 sk. cement plug at the surface with a Plug and Abandonment marker. Clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Original Signed F. H. MOOD TITLE Petroleum Engineer DATE January 20, 1972

APPROVED BY *Emmy Elmer* TITLE SUPERVISOR DIST #3 DATE JAN 20 1972

CONDITIONS OF APPROVAL, IF ANY: