

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.
14-20-601-1891

6. IF INDIAN, ALLOTTEE OR TRIBE NAME
Ute Mountain Tribe

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Ute Mountain Tribal "T"

9. WELL NO.

3

10. FIELD AND POOL, OR WILDCAT

Verde Gallup

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

**SE/4 NW/4 Section 28,
T-31-N, R-14-W**

12. COUNTY OR PARISH

San Juan

13. STATE

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

PAN AMERICAN PETROLEUM CORPORATION

3. ADDRESS OF OPERATOR

P. O. Box 480, Farmington, New Mexico

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)

At surface **2310 FWL and 1980 FWL**

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

5533 (RDB)

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

As a result of the above well ceasing to produce oil in commercial quantities, we propose to plug and abandon it as follows:

1. Pump 40 sacks cement down 5-1/2" casing with cementing plug, leaving cement plug about 3540. (300' off bottom and 53' above liner top. Hole and casing volume - 20 sacks, leaving 20 sacks squeezed into formation).
2. Pump 25 sacks cement down 5-1/2" - 8-5/8" annulus (about 160' fill).
3. Remove well head and surface equipment. *4. Plug casing with foam.*
4. Spot 5 sacks cement for surface plug (0-40') and erect abandonment marker.

Approval to plug and abandon subject well received from USGS on January 28, 1965,
Jerry Long to P. H. Hollingsworth.

18. I hereby certify that the foregoing is true and correct

SIGNED

ORIGINAL SIGNATURE
P. H. HOLLINGSWORTH

Fred L. Nabors, District Engineer

TITLE

DATE **January 28, 1965**

(This space for Federal or State office use)

APPROVED

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

JAN 29 1965

**JERRY W. LONG
DISTRICT ENGINEER**

TITLE

DATE

*See Instructions on Reverse Side

RECEIVED
FEB 1 1965
34 CON. COM.
DIST. 3

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.