

NO. OF COPIES RECEIVED	5
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	3

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name
8. Farm or Lease Name MADSEN-SELBY
9. Well No. 3
10. Field and Pool, or Wildcat
12. County SAN JUAN

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- ABANDON WELL
2. Name of Operator MINTS-KENASTON c/c BLOOMFIELD OIL FIELD SERVICE CO.
3. Address of Operator P.O. BOX 1641 BLOOMFIELD, NEW MEXICO 87413
4. Location of Well UNIT LETTER _____, 1080 FEET FROM THE N L LINE AND 940 FEET FROM THE E L LINE, SECTION 28 TOWNSHIP 29-N RANGE 11 W NMPM.
15. Elevation (Show whether DF, RT, GR, etc.)

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Move in and rig up. Re-enter old hole, if open. Run 3 3/4" bit on 2 3/8" tubing, clean out to 670'. Mix and spot 25 sacks cement. Wait on cement 6 to 8 hrs. Tag top of cement, cut and pull any free 5 1/2" casing or perforate casing at 180'. Mix and spot 25 sacks cement in open hole or squeeze up back side of casing to give 100' of fill-up or more. Clean and level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Jack Huff</u>	TITLE <u>V-Pres.</u>	DATE <u>5/5/78</u>
APPROVED BY <u>AR Wendrich</u>	TITLE <u></u>	DATE <u></u>
CONDITIONS OF APPROVAL, IF ANY:		