

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State Fee
5. State Oil & Gas Lease No.
OG-1826

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name - - -
2. Name of Operator Coastal States Gas Producing Company	8. Farm or Lease Name W. A. State
3. Address of Operator P. O. Box 235, Midland, Texas 79701	9. Well No. 2
4. Location of Well UNIT LETTER <u>D</u> , <u>469.4</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>32</u> TOWNSHIP <u>9-S</u> RANGE <u>33-E</u> NMPM.	10. Field and Pool, or Wildcat Flying "M" (San Andres)
15. Elevation (Show whether DF, RT, GR, etc.) 4325' GR	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	
		OTHER _____ <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Well No. 2 was completed as a single producing pumping oil well 9-20-67. Date of last production is 5-30-68. Well will be plugged and abandoned according to procedure outlined below. Work to be started as soon as possible.

- Spot 30 sacks cement across perforations at 4344' to 4483'.
- Spot 30 sacks cement at 4-1/2" casing stub.
- Spot 30 sacks cement at bottom of surface casing - 8-5/8" set at 286'.
- Spot 10 sacks cement in surface and install marker.

* 3054 Body Seal / 11-1-68
* 3054 1-1/2" Seal / 11-1-68

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Joe R. Howard TITLE Joe R. Howard DATE March 14, 1969
APPROVED BY Ledi A. Clement TITLE Director DATE 3/17/1969
CONDITIONS OF APPROVAL, IF ANY: