

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-85

SUNDRY NOTICES AND REPORTS ON WELLS		5a. Indicate Type of Lease	
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)		State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5. State Oil & Gas Lease No.	
2. Name of Operator		7. Unit Agreement Name	
Skelly Oil Company		8. Farm or Lease Name	
3. Address of Operator		M. H. Saunders	
P. O. Box 1351, Midland, Texas 79701		9. Well No.	
4. Location of Well		1	
UNIT LETTER <u>F</u> 1955 FEET FROM THE <u>North</u> LINE AND 1985 FEET FROM		10. Field and Pool, or Wildcat	
THE <u>West</u> LINE, SECTION <u>34</u> TOWNSHIP <u>14S</u> RANGE <u>33E</u> NMPM.		Saunders Permo Penn.	
15. Elevation (Show whether DF, RT, GR, etc.)		12. County	
Unknown		Lea	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well has become uneconomical to operate and we propose to plug it as follows:

- 1) Rig up workover rig.
- 2) Dump 50 sacks cement on bottom from 10,014' to 9614'.
- 3) Locate free point, cut off 5-1/2" casing at approximately 6200' and pull.
- 4) Spot cement plugs as follows:

50 sacks in and out of 5-1/2" stub
50 sacks across top of the Glorieta (6150' - 6000')
50 sacks in and out of 8-5/8" shoe (4350' - 4200')
10 sacks in top of 8-5/8" and cellar.

- 5) Set marker.

All intervals not cemented will be filled with 10# mud.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED (Signed) D. L. CROW TITLE Lead Clerk DATE Dec. 10, 1971

APPROVED BY [Signature] TITLE DATE DEC 12 1971

CONDITIONS OF APPROVAL, IF ANY:

[Faint, illegible handwritten text]

[Faint, illegible handwritten text]

[Faint, illegible handwritten text]

RECEIVED

DEC 13 1971

OIL CONSERVATION COMM.
HOUSTON, TEXAS