

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

**OIL CONSERVATION DIVISION**  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO. 30-025-26315
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. K-6875

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

7. Lease Name or Unit Agreement Name  N.E. Northeast Kemnitz
---

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER
--

8. Well No. 4
------------------

2. Name of Operator ELK OIL COMPANY
--

9. Pool name or Wildcat Kemnitz Cisco
--

3. Address of Operator Post Office Box 310, Roswell, New Mexico 88202-0310
---

4. Well Location Unit Letter <u>C</u> : <u>660</u> Feet From The <u>North</u> Line and <u>1980</u> Feet From The <u>West</u> Line Section <u>15</u> Township <u>16 South</u> Range <u>34 East</u> NMPM Lea County
---

10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4102 GR
---

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

<b>NOTICE OF INTENTION TO:</b>	<b>SUBSEQUENT REPORT OF:</b>
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: _____ <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: _____ <input type="checkbox"/>


12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

**Propose to Plug and Abandon Well as follows:**

- (1) Set CIBP @ 10,700' with 35' of cement on top.
- (2) Pull 8000' of 5½" Casing.
- (3) Set 100' plug in and out of 5½" casing stub @ 8000'.
- (4) Set 100' plug top of Glorieta @ 6125'.
- (5) Set 100' plug @ base of 8 5/8" casing @ 4525'.
- (6) Set 100' plug inside 8 5/8" casing across Salt @ 7600'.
- (7) Set 10' plug @ surface.
- (8) Place 4' X 4' dry hole marker.
- (9) Clean and level location.

Place mud between all plugs.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE 	TITLE <u>President</u>	DATE <u>1/4/91</u>
TYPE OR PRINT NAME <u>Joseph J. Kelly</u>		TELEPHONE NO. <u>(505)623-3190</u>

(This space for State Use) ORIGINAL SIGNED BY JERRY SEXTON  
DISTRICT SUPERVISOR TITLE \_\_\_\_\_ DATE \_\_\_\_\_

APPROVED BY \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

0991