

NO. OF COPIES RECEIVED	
DISTRIBUTION	
DATE	
TIME	
S.G.S.	
FIELD OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes O11  
C-102 and C-101  
Effective 1-1-65

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR OPERATIONS TO BE PLANNED TO BE PERFORMED ON A DIFFERENT RESERVOIR. USE THIS FORM FOR PERMIT AND REPORTING FOR THE RESERVOIR.)

OIL WELL     GAS WELL     OTHER

Name of Operator  
**ELK OIL COMPANY**

Address of Operator  
**Post Office Box 310, Roswell, New Mexico 88202-0310**

Location of Well  
UNIT LETTER **I**    **2310** FEET FROM THE **South** LINE AND **990** FEET FROM  
THE **East** LINE, SECTION **13** TOWNSHIP **16S** RANGE **34E** N.M.P.M.

13. Elevation (Show whether DF, KT, GR, etc.)  
**4051' GR**

5a. Indicate Type of Lease  
State  Fee

5. State Oil & Gas Lease No.

7. Unit Agreement Name

6. Form of Lease Name  
**Chace-McKamey**

9. Well No.  
**1**

10. Field and Pool, or Unit, Name  
**Townsend Permo Upper Penn**

12. County  
**Lea**

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
<input type="checkbox"/> PERFORM REMEDIAL WORK	<input checked="" type="checkbox"/> PLUG AND ABANDON	<input type="checkbox"/> REMEDIAL WORK	<input type="checkbox"/> ALTERING CASING
<input type="checkbox"/> UNEXPECTEDLY ABANDON	<input type="checkbox"/> CHANGE PLANS	<input type="checkbox"/> COMMENCE DRILLING OPNS.	<input checked="" type="checkbox"/> PLUG AND ABANDONMENT
<input type="checkbox"/> CLEAN OR ALTER CASING	<input type="checkbox"/> OTHER	<input type="checkbox"/> CASING TEST AND CEMENT JOB	<input type="checkbox"/>


Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

**Proposed plugging procedure as follows:**

- 1) Set 35' cement on Cast Iron Bridge Plug @ 4490'.
- 2) Set 25 sx plug @ 4140' and tag.
- 3) Set 100' plug 50' in and out casing stub, tag.
- 4) Set 100' plug @ top of anhydrite (1745').
- 5) Set 10 sx plug @ surface.
- 6) Install dry hole marker and clean up location.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED BY:  TITLE: **President** DATE: **09/22/88**

APPROVED BY: \_\_\_\_\_ TITLE: \_\_\_\_\_ DATE: \_\_\_\_\_

ADDITIONS OF APPROVAL, IF ANY:

SEP 20 1988