

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-12379
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. B-93125
7. Lease Name or Unit Agreement Name West Dollarhide Drinkard Unit
8. Well No. 79
9. Pool name or Wildcat Dollarhide Tubbs Drinkard

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <u>Inject</u>
2. Name of Operator Texaco Exploration & Production, Inc.
3. Address of Operator P. O. Box 3109, Midland, TX 79702
4. Well Location Unit Letter <u>D 4</u> <u>666</u> Feet From The <u>North</u> Line and <u>660</u> Feet From The <u>West</u> Line Section <u>5</u> Township <u>25 S</u> Range <u>38 E</u> NMPM Lea County
10. Elevation (Show whether DF, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: _____ <input type="checkbox"/>		OTHER: _____ <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) Notify Oil Conservation Division 24 hours before move-in
- 2) NUBOP, RIH with CICR set @ 5700, squeeze with 60 sx cement
- 3) Circulate well with 9.8 mud
- 4) Spot 20 sx cement @ 4080 to 3980 (San Andres)
- 5) Spot 40 sx cement @ 3870 to 3570 (Queen)
- 6) Perf 4 holes @ 2550, squeeze with 50 sx cement
- 7) Perf 4 holes @ 1271, squeeze with 150 sx cement
- 8) SPot 10 sx cement 30 to surface
- 9) NDBOP, cut off wellhead, install dry hole marker

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE David W. Meas TITLE Petroleum Engineer DATE 9/23/97

TYPE OR PRINT NAME _____ TELEPHONE NO. _____

(This space for State Approval) ORIGINAL SIGNED BY CHRIS WILLIAMS ORIGINAL SIGNED BY GARY WINK
DISTRICT SUPERVISOR FIELD REP. II

APPROVED BY _____ TITLE _____ DATE 09 23 1997

CONDITIONS OF APPROVAL, IF ANY:

JCS 40

~~XXXXXXXXXX~~