Submit 1 Copy To Appropriate District State of New Mexico Form C-103 Office Revised July 18, 2013 Energy, Minerals and Natural Resources District I - (575) 393-6161 WELL API NO. 1625 N. French Dr., Hobbs, NM 88240 District II - (575) 748-1283 30-021-20062 OIL CONSERVATION DIVISION 811 S. First St., Artesia, NM 88210 5. Indicate Type of Lease District III - (505) 334-6178 1220 South St. Francis Dr. STATE FEE  $\boxtimes$ 1000 Rio Brazos Rd., Aztee, NM 87410 Santa Fe, NM 87505 State Oil & Gas Lease No. District IV - (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM 87505 SUNDRY NOTICES AND REPORTS ON WELLS 7. Lease Name or Unit Agreement Name (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR, USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH Hayoz 8. Well Number 1. Type of Well: Oil Well Gas Well Other CO2 002 2. Name of Operator Breitburn Operating LP 9. OGRID Number 370080 10. Pool name or Wildcat 3. Address of Operator 1401 McKinney St., Suite 2400 Houston, TX 77010 Tubb 4. Well Location Unit Letter E: 1980 feet from the North line and 660 feet from the West line Section 12 Township 19N Range 30E **NMPM** Harding County 11. Elevation (Show whether DR, RKB, RT, GR, etc.) GR 4483' 12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: ALTERING CASING PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK  $\boxtimes$ TEMPORARILY ABANDON **CHANGE PLANS** COMMENCE DRILLING OPNS. P AND A PULL OR ALTER CASING MULTIPLE COMPL  $\Box$ CASING/CEMENT JOB DOWNHOLE COMMINGLE CLOSED-LOOP SYSTEM OTHER:  $\Box$ OTHER: Permit Extension 13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion. Breitburn Operating LP intends to plug and abandon this well. Procedure as follows: MI RU single pole rig Set 5 ½" CIBP at 1980' (approximately 50' above top perfs) Spot 6 sx. Class A cement on top of CIBP (calc 53' fillup, top of plug at 1927') Spot cement plug inside 5 1/2" casing at surface from 257° to surface with 45 sx Class A Cement. (calc 385 fillup, cement to surface) Cut off wellhead and install P&A Marker in accordance with NMOCD guidelines RD MO rig, remove all equipment from site. Restore site. Spud Date: Rig Release Date: I hereby certify that the information above is true and complete to the best of my knowledge and belief. Lolly Rome Lea **SIGNATURE** TITLE: Agent DATE: 06/09/2016 Type or print name Shelly Doescher E-mail address: shelly\_doescher @yahoo.com PHONE: 505-320-5682

Tomes

APPROVED BY: \_/

Conditions of Approval (if any

## Hayoz #2

