HOBBS OCD

SUNDRY NOTICES AND REPORTS ON WELLS Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160 - 3 (APD) for such proposals. SUBMIT IN TRIPLICATE - Other instructions on reverse side. 1. Type of Well Gas Well Other 2. Name of Operator SHACKELFORD OIL CO 3a Address 11417 W COUNTY RD 33 MIDLAND TX 79707 4. Location of Well (Footage, Sec., T., R., M., or Survey Description) 990' FSL & 1980' FWL SEC 35 T19S R33E				FORM APPROVED OM B No. 1004-0135 Expires: January 31, 2004 5. Lease Serial No. NM 27572 6. If Indian, Allottee or Tribe Name 7. If Unit or CA/Agreement, Name at 8. Well Name and No. LAGUNA DEEP FEDERAL 9. API Well No. 30-025-27152 10. Field and Pool, or Exploratory Are FEAS, BONE SPRING 11. County or Parish, State LEA COUNTY, NM	#3
12. CHECK AI	PPROPRIATE BOX(ES) TO INDIC	CATE NAT	URE OF NOTICE. R	EPORT, OR OTHER DATA	
TYPE OF SUBMISSION	Thornas Borgas, To History		YPE OF ACTION	Di OKI, OK OTHER DATA	
Notice of Intent					
14. I hereby certify that the foreg Name (Printed/Typed)	going is true and correct	1			
			PRESIDENT/OWNER		
Signature /		Date	11	/06/2017	
t	THIS SPACE FOR FEDE	RAL OR	STATE OFFICE	USE	
Approved by C. N. i'm Mev Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon. Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person States any false, fictitious or fraudulent statements or representations as to any matter within				1- CFO	
(Instructions on page 2)					Annual Control of the

MAB/OCD 11/20/2017

BUREAU OF LAND MANAGEMENT Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 575-234-5972

Temporary Abandonment of Wells on Federal Lands Conditions of Approval

A temporarily abandoned well is defined as a completion that is not capable of production in paying quantities but which may have value as a service well. Pursuant to 43 CFR 3162.3-4 (c), no well may be temporarily abandoned for more than 30 days without the prior approval of the authorized officer.

Temporary Abandonment (TA) status approval requires a successful mechanical or casing integrity test as follows:

- 1. A Notice of Intent (NOI) Sundry Notice (Form 3160-5) requesting approval to run a mechanical integrity test (MIT) or casing integrity test (CIT).
- 2. A description of the temporary abandonment procedure.
 - a. A bridge plug or packer must be installed as close to 50 feet above any open perforations or open hole as possible. If a cement plug is used, the top of the cement must be verified by tagging. CIBP must be capped with minimum 25 sacks cement, placed with tubing, or 35 feet of cement if placed with bailer.
 - b. The wellbore must be filled with corrosion inhibited fluid and pressure tested to 500 psi. The casing shall be capable of holding this pressure for at least 30 minutes. Any leak-off will be evaluated.
 - c. All downhole production/injection equipment (tubing, rods, etc.) shall be removed from the casing if they are not isolated by a packer.
 - d. A bradenhead test must be conducted. If the test indicates a problem exists, a remedial plan and time frame for remediation shall be submitted within ninety (90) days of the test.
 - e. Contact the appropriate BLM office at least 24 hours prior to the scheduled Casing Integrity Test. For wells in Eddy County, 575-361-2822; Lea County 575-393-3612.
- 3. Provides justification why the well should be temporarily abandoned rather than permanently plugged and abandoned and an estimated date that the well will be returned to beneficial use or plugged and abandoned. 43 CFR 3162.3-4 (a) The operator shall promptly plug and abandon...wells in which oil or gas is not encountered in paying quantities...

Wells that successfully pass the casing integrity test may be approved for Temporary Abandonment (TA) status provided that the operator:

- 1. Submits a subsequent Sundry Notice (Form 3160-5) requesting TA approval with well bore diagram with all perforations and CIBP's and tops of cement on CIBP's.
- 2. Describes the temporary abandonment procedure.
- 3. Attaches a clear copy or the original of the pressure test chart.
- Give justification to allow well to be place in TA status and plan for future use of well with time frame that well will be place back on line or plans to P&A well will be submitted.

If the well does not pass the casing integrity test, then the operator shall within 30 days submit to BLM for approval one of the following:

- 1. A procedure to repair the casing so that a TA approval can be granted.
- 2. A procedure to plug and abandon the well.

Laguna Deep Federal #3

- 1. Well is approved to be TA for a period of 12 months or until 11/16/2018
- 2. Must submit NOI to recomplete or NOI to P&A. Must be submitted by 11/16/2018
- 3. COA's met at this time.