

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name	
2. Name of Operator Midwest Oil Corporation		8. Farm or Lease Name Cross A	
3. Address of Operator 1500 Wilco Bldg., Midland, TX 79701		9. Well No. 1	
4. Location of Well UNIT LETTER <u>K</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>35</u> TOWNSHIP <u>9-S</u> RANGE <u>33-E</u> NMPM.		10. Field and Pool, or Wildcat Vada Penn	
15. Elevation (Show whether DF, RT, GR, etc.) 4287 Gr.		12. County Lea	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐  
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐  
ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

### History:

11 3/4" Csg. Set @ 320' w/ 325 sx cmt. (circulated)  
8 5/8" Csg Set @ 3945' w/400 sx cmt.  
5 1/2" Csg. set @ 9724' w/650 sx cmt.  
Perforated 9688'.

Propose to plug & abandon as follows:

Set CIBP @ 9650' & w/35 sx cement on plug in 5 1/2" casing  
Pull & recover casing from appx. 5000'  
Set 100' cmt plug in & out of stub.  
Set 100' cmt plug @ base of Intermediate casing.  
Set 100' cmt plug in & out of intermediate stub.  
Set 100' cmt plug @ base of surface casing.  
Set 10 sx cmt. @ surface & install dry hole marker.

100' cmt plugs will be set above Wolfcamp Abo. & Glorietta Sections if casing is recovered through sections.

Mud will be used to set plugs.

The Commission will be notified 24 hours prior to setting cement plugs.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Gene Melford

TITLE Agent

DATE 11-9-73

Cert. Signed by

Agent

APPROVED BY \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

TITLE \_\_\_\_\_

DATE \_\_\_\_\_

NOV 12 1973

